

Section 3

Electrical System, Instruments

Specifications1

Group 32: Alternator, Bosch

Special instructions	4
Disassembly	4
Test	6
Assembling, Installation	8
Voltage regulator	9
Alternator test	9
Testing and adjusting voltage regulator	10
Service diagnosis	11
Quick check of charging system ..	12
Spare Parts Illustrations: Alter- nator and Starter Motor	13

Group 33: Starter Motor

Tools, removal, disassembly	14
Inspection	16
Assembling	19

Group 34: Ignition System

Breakerless ignition system	22
Replacing impulse sender	22
Check of breakerless ignition system	27

Group 35: Lights

Headlamps, headlamp alignment ..	28
Front turn signal lights, tail lights	29

Group 36: Standard Electrical Equipment

Ignition switch, turn signal switch, flasher unit	30
Horn, control relays	31
Wiper units	32
Bulb Failure Warning Light	33

Group 38: Instruments

Testing: speedometer w. odometer, speedometer cable	34
temperature gauge	35
Testing: temperature sensor, fuel gauge, fuel gauge sender	35
Replacing: instrument cluster, tacho- meter, speedometer, printed circuit	36
Replacing fuel gauge sending unit, clock, temperature/fuel gauge	37
Replacing voltage stabilizer, tempera- ture sender unit	38
Spare Parts illustrations: Instruments	38
Dashboard electrics	39

Specifications

	Metric	US
Battery 12 V, 60 Ah, negative ground		
Specific gravity of electrolyte:		
Fully charged	1,28	
When re-charging is requested	1,21	
Charging current when recharging	5,5 Amps	
 Alternator Bosch K1-14 V 55A 20		
Output	770 W	
Max. amp.	55 Amps	
Max. speed	225 r/s	135 00 rpm
Direction of rotation	Clockwise	
Ratio, engine/alternator	1:2	
Slip rings: minimum diameter	31.5 mm	1.3"
max. out-of-round	0.03 mm	0.0012"
Stator coil resistance	0.14 ohm + 10%	
Rotor coil resistance	4.0 ohms + 10%	
Output test	48 Amps at 3000 rpm	
	and approx. 13 V	
 Voltage Regulator Bosch K1-14 V 55A 20		
Control voltage of 4000 rpm	13.9 14.8 V	
Load current, lower two contacts	45±1 Amp	
Control range, between upper and lower contact sets	0.04 Volts	
Load current, upper two contacts	3-8 Amp	
 Starter Motor Bosch GF 12 V 1.1 PS		
Direction of rotation	Clockwise	
Output	810 W (1.1 hp)	
Pinion teeth	9	
No. of brushes	4	
 Mechanical test specifications		
Armature end float	0.01-0.3 mm	0.002-0.012"
Brush spring tension	14-16 N	3.1-3.5 lbs
Distance from pinion end to ring gear face	1.2-4.4 mm	0.047-0.173"
Frictional torque of rotor brake	25-40 Ncm	2.17-3.81 lb.in
Pinion idling torque	14-18 Ncm	1.20-1.56 lb.in
Backlash	0.3-0.5 mm	0.006-0.00
Pinion pitch	2.12	
Commutator min. diameter	33.5 mm	1.318"
Brush min. length	13 mm	0.52 "
 Electrical test specifications		
Free-running:		
11.5 Volts and 30-50 Amps	97-130 r/s	5800-7800 rpm
Loaded:		
9.0 Volts and 185-220 Amps	17.5-22.5 r/s	1050-1350 rpm
Locked:		
1 Volts and 400-490 Amps	0 r/s	0 rpm
 Solenoid		
Cut-in voltage	Min 8 Volts	

Ignition System

Type	Breakerless electronic ignition	
Firing order	1-3-4-2	
Ignition timing, vacuum unit disconnected	5° B.T.D.C. at 700 rpm	
Spark plugs	Bosch W 200 T 35 or equivalent	
Gap	0.7–0.8 mm	0.028–0.0032"
Tightening torque	25–30 Nm	18–22 lb.ft

Distributor

	Man. transm.	Aut. transm.
Bosch No.	0237 002 002	0237 002 003
Volvo P/N	462896	462762

Ignition coil

Bosch No.	0221 122 006	0221 122 006
Volvo P/N	1219230	1219230

Electronic module

Bosch No.	0221 100 005	0227 100 005
Volvo P/N	462763	462763

Centrifugal governor

Total advance, distributor degrees	14.5±1	14.5±1
Advance begins at, distributor rpm	430–600	430–600
Distributor rpm at 5° advance	830–1010	830–1010
10°	1230–1400	1200–1400
full advance	1600	2200

Vacuum unit

Retard distributor degrees	2.5±1°	2.5±1
Retard begins at, in Hg	1.2–4.4	1.2–4.4
1° retard at, in Hg	1.8–4.6	1.8–4.6
Retard ends at, in Hg	4.8	4.8

Bulbs

	US bulb No.	Power	Socket	No. of bulbs
Headlights	7" Type 2 Sealed Beam			2
Position lights, front	67	5 W/4 cp	Ba 15s	2
Turn signals, front	1073	21 W/32 cp	Ba 15s	2
rear	1073	21 W/32 cp	Ba 15s	2
Tail lights	67	5 W/4 cp	Ba 15s	2
Stop lights	1073	21 W/32 cp	Ba 15s	2
Back-up lights	1073	21 W/32 cp	Ba 15s	2
License plate light		5 W	S 8.5	2
Interior light		10 W	S 8.5	1 (245:2)
Glove box light		2 W	Ba 9s	1
Instrument panel light		2 W	W 2.2 d	3
Engine compartment light		15 W	S 8.5	1
Light, control panel		1.2 W	W 1.8 d	3
–shift positions		1.2 W	W 1.8 d	1
–rear ash tray		1.2 W	W 1.8 d	1
–belt lock mechanism		1.2 W	W 1.8 d	1
Warning charging		1.2 W	W 1.8 d	1
and – oil pressure		1.2 W	W 1.8 d	1
indicator – parking brake		1.2 W	W 1.8 d	1

lights	— brake failure	1.2 W	W 1.8 d	1
	— bulb failure	1.2 W	W 1.8 d	1
	— turn signals	1.2 W	W 1.8 d	2
Warning	— upper beam	1.2 W	W 1.8 d	1
	— overdrive	1.2 W	W 1.8 d	1
	— el heated rear window	1.2 W	W 1.8 d	1
	— seat belt	1.2 W	W 1.8 d	1

Fuses

	No. of fuses
8 amp	4
5 amp	6
16 amp	2

Electrically heated rear window

Power drain 150 W

Speedometer gears

Model	Trans.	Rear axle ratio	Small gear		Large gear		Ratio
			P/N	Teeth	P/N	Teeth	
242, 244, 245	M 40	3.91	381600	20	381601	6	3,33
		4.10	381603	21	381601	6	3.50
		4.30	381604	22	381601	6	3.66
	M 41	4.10	381659	21	380682	6	3.50
		4.30	381660	22	380682	6	3.66
	BW 35	3.91	381600	21	381602	6	3.50
		4.10	381603	20	381602	6	3.33

o. of bulbs

1 (245:2)


3
1
3
1
1
1
1
1

Group 32

Alternator, Bosch

Special instructions for work on alternator equipment


1. When replacing or installing battery, make sure that proper polarity is observed. A misconnected battery will immediately ruin the rectifiers.
2. Never run the alternator with the main circuit broken. The battery and/or alternator and regulator leads must never be disconnected while the engine is running.
3. No attempt should be made to polarize the alternator.
4. When battery in vehicle disconnect the battery ground cable.
5. When using an extra battery as a starting aid, connect it in parallel.
6. When are welding on the vehicle, disconnect the battery ground cable as well as the B+ lead on the alternator and the two-pin plug at the voltage regulator. The welding unit should always be connected close to the weld.



Removing alternator

Op. No. 32102 = replace alternator


Op. No. 32104 = rebuild alternator



1. Disconnect the battery ground cable.
2. Disconnect the leads to the alternator.
3. Remove the bolt for the adjusting arm.
4. Remove the bolt securing the alternator to the engine block.
5. Remove fan belt and lift out the alternator.


Disassembly

1. Remove nut and washer for pulley. Pull off pulley and fan. Remove the key.
2. Remove the brush holder retaining screws. Remove the brush holder.




VOLVO
103805

3. Remove nuts and bolts connecting the alternator end shields.
Remove front end shield from stator and rear end shield assembly.



VOLVO

4. Press out the rotor from the front end shield.



VOLVO
103807

5. Remove the screws retaining the front ball bearing.
Press out the bearing.



VOLVO
103808

6. Remove the nuts for the plus diode plate. Lift up and bend the plate aside.
7. Solder loose the stator connections from the terminal points.
Lift off the stator.

Test of disassembled alternator

Stator

Test stator insulation.

Connect a 40 Volt alternating current across ground and phase terminal.

Correct resistance: indefinite



Test stator coil resistance.

Connect the test instrument across the phase terminals.

Correct resistance: 0.14 ohm + 10%.




Rotor

Test rotor insulation.

Connect a 40 Volt alternating current across rotor ground and a slip ring.

Correct resistance: indefinite.



Test rotor coil resistance.

Connect the test instrument across the slip rings.


Correct resistance: 4.0 ohms + 10%

Slip rings which are burned or damaged should be turned in a lathe. Use tail stock.

Slip ring minimum diameter is 31.5 mm = 1.3".

Use a dial indicator to check out-of-round, maximum 0.03 mm = 0.0012".





VOLVO
106639


Brush holder

Test insulation.

Use 40 Volt alternating current.

Correct reading: indefinite

Check that minimum brush length is 14 mm = 0.55"



VOLVO
103314

Diodes

Test the diodes with a diode tester.


Replace defective diodes as follows:

Plus diodes

1. Solder loose the plus diode plate from the terminals. Press out the defective diode.
2. Calibrate the diode hole in the plate. Use tool Bosch EFU 57/0/3 and 57/0/5.
3. Press in the new diode. Lubricating with silicone oil facilitates installation.
4. Paint the new diode and any bare spots on the outside of the plus diode plate. Use chlorinated rubber enamel Bosch Ft 87 V1, or corresponding.
5. Solder the plus diode plate to the terminals. Re-test.

Minus diodes


1. Solder loose the minus diodes from the terminals. Remove the plus diode plate assembly.
2. Press out the defective diode.
3. Press in the new diode. Lubricating with silicone oil facilitates installation.
4. Solder the negative diodes to the terminals. Re-test.




VOLVO
106640

Magnetizing diodes


In case of defective magnetizing diodes, replace the entire plate assembly with three diodes.



VOLVO
106641



VOLVO
103815




VOLVO
103816

Alternator terminals

- | | |
|----------|----------------------------|
| 1. DF | To field winding |
| 2. 61/D+ | From magnetizing rectifier |
| 3. B+ | To battery |

Assembling alternator

1. Install the stator in the slip ring end shield. Solder the stator wires to the terminals. Install the plus diode plate assembly.
2. Grease the drive end ball bearing with grease Bosch Ft 1 V 4 or corresponding. Install bearing assembly in the drive end bearing shield.
3. Press drive end bearing shield onto the rotor. Install the spacer ring.
4. Grease the slip ring end shield bearing with grease Bosch Ft 1 V 35 or corresponding. Coat the slip ring end shield bearing seat with Molykote. Assemble the alternator. Do not forget to install the spring on the slip ring end shield bearing seat. Assemble alternator components. Torque retaining screws to 3.6–4.3 lb.ft. = 5.0–6.9 Nm and nuts to 3.3–4.3 lb.ft. = 4.5–6.0 Nm.
5. Install the brush holder.
6. Install key, fan, spacer and pulley. Position the washer and torque the nut to 29 lb.ft. = 40 Nm.
7. Test on a test bench before installation.



VOLVO
104-800

Installing alternator

1. Install alternator and fan belt at the same time.
2. Install attaching bolts and tensioner. Do not tighten the tensioner finally.
3. Adjust the belt tension. It should be possible to depress the belt $3/8'' = 8 \text{ mm}$ halfway between the pulleys.

Secure the alternator.

NOTE: Force may only be applied to the front end of the alternator when adjusting belt tension.

4. Re-attach alternator wires.
5. Re-connect the battery ground cable.

Replacing voltage regulator

Replace voltage regulator = Op. No. 32205

1. Disconnect the battery ground cable.
 2. Pull the plug out of the voltage regulator.
 3. Remove the screws and change the regulator.
 4. Install the new regulator and insert the plug.
 5. Reconnect the battery ground cable.
- For regulator adjustment, see "Test the voltage regulator".

Test of alternator and voltage regulator

For all tests of alternator equipment, fixed clamps should be used. So-called crocodile clamps should not be used as they have a certain tendency to loosen. A loose lead can result in alternator and regulator being damaged. Disconnect the battery before connecting any instruments.

Test of alternator circuit

Before any tests on the alternator or regulator in the vehicle are made, check battery and wiring for fault in leads or insulation, loose or corroded lead terminals and poor ground. **Check the fan belt.** Any of the fault mentioned must be repaired before electrical checks are started.

Battery test

Test the battery with a hydrometer and battery tester. If the battery is not fully charged, remove it from the car and charge it or replace it with a new one if necessary. A fully charged battery which is otherwise in good condition should always be used when testing.

Voltage drop test


This test is made to check the leads between the alternator and the battery and also the battery ground cable. The test should be made with a fully charged battery in good condition. The battery connections should be well cleaned and tightened. Load the alternator with approx 10 amps. Suitable load: headlights switched on. With the engine running

and the alternator supplying 10 amps, measure with a voltmeter the voltage between positive pole of the battery and B+ on the alternator. If the voltage at this test exceeds 0.3 volt, there is a fault in cable or contact, which must be remedied immediately. After repairing defective leads or contacts, measure again. With the same load as above, measure voltage drop between negative pole of the battery and alternator terminal D-. The voltage drop must not exceed 0.2 Volt. If the voltage drop exceeds 0.2 Volt, check battery ground, alternator contact with engine and engine contact with the chassis. After necessary repairs, measure again.

Alternator test

(In a test bench or in the vehicle)

Test of charging system in vehicle = Op. No. 32174



Wiring diagram for testing alternator

- | | |
|-----------------------------------|---------------------------|
| A. Alternator | D. Ammeter 0—50 amps. |
| B. Control lamp 12 volts, 2 watts | E. Battery 60 ampèrehours |
| C. Voltmeter 0—20 volt | F. Load resistance |

Connect the alternator as shown. Run 6000 rpm. Regulate voltage to approx 14 volts by load resistance F. The alternator should produce 55 amps at 6000 rpm and 14 Volts.


At the same time check to make sure that the charging warning lamp does not light or glow.

If the alternator does not meet above requirements, first check brushes and diodes.

Testing and adjusting voltage regulator

(In a test bench or in the vehicle)

Connect the regulator to an alternator in good condition.



Wiring diagram for testing voltage regulator

- | | |
|--------------------------------------|---------------------------|
| A. Alternator | E. Ammeter 0–50 amps. |
| B. Voltage lamp 12 volts | F. Regulator resistance |
| C. Control lamp 12 volts,
2 watts | G. Battery 60 ampèrehours |
| D. Voltmeter 0–20 volts | H. Load resistance |

Load the alternator with 28–30 amps at an alternator rpm of 4000 (engine rpm 2000).

Rapidly lower the speed to alternator rpm 1000 (engine idling speed). Then raise the alternator rpm again to 4000 (engine rpm 2000). Check that the load is 28–30 amps. Read the voltmeter. The voltage should be 14.0–15.0 Volts.


The reading should be made within 30 seconds after the test has begun. Reduce the load on the alternator to 3–8 amps and read the regulating voltage. This voltage should now lie within the tolerance 0 volt to minus 0.3 volt in relation to the first reading.

If the regulating voltage in the upper regulating range is too high or too low in relation to the lower regulating range (0 volt to minus 0.3 volt) this is adjusted by bending the holder for the left (lower) contact and correcting at the same time the gap between the right (upper) contact and the movable contact.


If the holder is bent towards the right (upper) contact, the regulating voltage in the upper regulating range will drop. To avoid faulty adjustments due to residual magnetism in the regulator core, it is necessary to reduce alternator speed to idle after each adjustment and then increase speed and make a new reading.

(If the adjusting is comprehensive and the regulator is hot, it can be cooled to ambient temperature by compressed air before final reading.)

The regulating voltage in the lower regulating range is adjusted by bending the tensioner 3 for the bimetallic spring, see below:



If the tensioner is bent downwards, the regulating voltage should drop, if bent upwards the opposite should be the effect.



Voltage regulator

- | | |
|--|---|
| 1. Regulator contact for lower control range | 3. Spring tensioner |
| 2. Regulator contact for upper control range | 4. Spring upper section:
Steel spring
Lower section:
Bi-metal spring |

Service Diagnosis

Condition: Warning lamp does not light with engine off.

Action

Test lamp (12 volts 2 watts) between B+ and 61/D+ on alternator lights.

Test lamp between B+ and 61/D+ does not light. Test lamp between 61/D+ and ground lights.

Test lamp between 61/D+ and ground gives a weak light. Remove the plug at the regulator and connect an ammeter between B+ and DF on the alternator. Ammeter reading:

Possible cause

Warning lamp burned out or open circuit to D+ on regulator.

A positive diode shorted.

0 amp.:

Worn brushes, oxidized slip rings or breakage in rotor coil.

2–2.5 amp.:

Open circuit in regulator or in lead DF from regulator to DF on alternator.

Condition: Warning lamp lights with engine off or running.

Action

Disconnect the plug at the regulator:
Control lamp still lights.

Warning lamp goes out. Re-install the plug in the regulator and connect an ammeter between B+ and D+ on the alternator.

Ammeter reading:

Possible cause

Circuit shorted between D+ on the regulator and 61/D on the alternator.

Less than 2.0–2.5 amps:

Defective regulator (breakage).

More than 2.0–2.5 amps:

Circuit shorted between DF on regulator and DF on alternator.

Coil shorted.

Condition: Warning lamp lights with engine off but starts to give a weak light when engine is running.

Action:

Test lamp between B+ and 61/D+ on the alternator with the engine running:
Does not light.

Gives a weak light.

Install new regulator.
Test lamp between B+ and 61/D+:
Does not light.

Gives a weak light.

Possible cause

Transition resistance in the charging circuit or in the lead to the warning lamp.

Defective regulator (overcharging of the battery) or defective alternator (insufficient charging of the battery).


Removed regulator defective.

Defective alternator.


start here




Quick check of charging system



Spare Parts Illustrations




Alternator



VOLVO PARTS
1 030 13035

Starter Motor




VOLVO PARTS
1 030 13027

alternator and
voltage regulator

Replace voltage regulator


Group 33

Starter Motor



Tools


EF 2722	Sleeve and drift for installing circlip
EFAL 3	Smoothing drift
EF 2649/1	Smoothing drift
EF 2649	Drift for installing bushing



Removal


Replace starter motor = Op. No. 33118
Rebuild starter motor = Op. No. 33102

- Disconnect the battery ground cable.
- Disconnect the leads from the starter motor.
- Remove the bolts which hold the starter motor to the timing gear housing.
- Remove the starter.




Disassembly

- Remove the two screws retaining the cover.
- Remove the cover.




VOLVO
109 971

Remove lock ring and spacer rings.
Remove the two screws retaining the commutator end shield.
Remove the shield.




VOLVO
109 972

Lift up the brushes.
Remove the brush holder bridge from the armature shaft.
The minus brushes are retained together with the brush holder bridge.
The plus brushes stay with the field coils.




VOLVO
109 973

Remove the nut connecting the field coil to the solenoid.
Remove the screws retaining the solenoid to the pinion end shield.
Remove the solenoid.




VOLVO
109 974


Remove the stator assembly from the pinion end shield.



Remove rubber stop and steel washer.
Remove the pivot pin for the pinion lever. Lift out armature assembly from the pinion drive shield.




Use a fitting sleeve to remove the end stop.
Remove lock ring, stop and pinion.




Inspection

Check the armature for damages and wear. Replace the armature if the shaft is worn or warped.
Turn the commutator in a lathe if it is scored, pitted or unevenly worn.
Minimum diameter is 33 mm = 1.300".
Max. permitted out-of-round is 0.08 mm = 0.00032".



Use a Mica undercutter to undercut 0.4 mm = 0.008".
If no machine is available, use a properly ground hacksaw blade.




- A. Incorrect
- B. Correct




Use a "Growler" to check the armature for shorts. Switch on and hold a hacksaw blade close to the armature. If the blade vibrates in any position, one of the following faults can exist:

- short to ground
- commutator shorted
- windings shorted

Replace the rotor if faulty.



Use 40 Volts AC to check the stator coil insulation.




Check end shields and brush holder.

Replace worn or damaged parts.

No more than 0.005" (0.12 mm) bushing play is permitted.

Check other parts and replace if worn or damaged.

The lock ring should always be replaced as it might have been damaged or lost its tension when removed.



Installing bushings


Before installation, new bushings should be immersed in oil, Bosch 01 1 V 13 or similar, for at least 1/2 hour. Otherwise their service time will be considerably reduced.

The bushings are made to correct dimensions and must not be machined. Any machining will block the pore holes which in turn obstructs the lubricating ability.

Use Bosch special tool EF 2649 to press out the old bushing.

Clean the hole and remove any burrs.

Use same Bosch tool to press in the new bushing.




Replacing field coil

Mark poles and housing. The poles should be re-installed in exact positions.


Place the stator in a clamping device, Bosch EFAW 9 or similar, and slacken the pole screws.


Remove the stator from the clamping device.

Remove poles and field coils.



Position the new field coils and the poles in the stator. Heat the field coils slightly before installation. Orientate the poles according to markings.






VOLVO
109 983

Replacing brushes

Brushes shorter than $9/16'' = 14 \text{ mm}$ should be replaced.

1. Solder loose the brushes from their attachments.
2. Solder on the new brushes. Use a sufficiently hot soldering iron.

Do not allow any solder to run down in the brush leads. This would stiffen the leads and prohibit free movements.




VOLVO
102 969

Assembling starter motor


Lubricate as shown. Use Bosch lubricants or similar:

1. Ft 2 V3 Apply a thin layer of grease on insulation washers, shaft bearing surfaces, spacer washers and lock ring.
2. 01 1 V13 Immerse the bushing in oil 1/2 hour before installation.
3. Ft 2 V3 Apply generously of grease in the armature gear guides and in the pinion lever groove.
4. Ft 2 V3 Apply a thin layer of grease on the shaft bearing surfaces.
5. 01 1 V13 Immerse the bushings in oil 1/2 hour before installation.
6. Ft 2 V3 Lubricate shift lever joints and solenoid iron core with a thin layer of grease.

Install pinion, stop ring and lock ring. Tighten the stop ring into place with a fitting puller.




VOLVO
108 984




VOLVO
108 985

- Attach the shift lever to the pinion.
- Install the armature in the drive end shield.
- Install the shift lever pivot stud.




Install steel washer and rubber stop.

VOLVO
109 986




Install solenoid.

VOLVO
109 987




Install stator.

VOLVO
109 988




Install brush holder bridge and brushes.


VOLVO
109 989



Install commutator end shield.
Install the two long screws that hold the starter motor together.



Install spacer washers and lock ring. The armature end play should be 0.002–0.006" = 0.05–0.3 mm.
Install sufficient amount of washers to keep the end play within these limits.
Attach the small cover over the shaft end.




Installing starter motor

Connect the starter motor leads.
Reconnect the battery ground cable.
Start the engine to check the starter motor function.

Group 34

Ignition System



1. Primary connection 2. Attaching screw 3. Vacuum regulator


Breakerless Electronic Ignition System

Removing distributor

Remove the ignition high tension leads from the distributor cap.

Disconnect distributor wire and vacuum line at the distributor.


Remove the retaining bolt. Lift the distributor straight up.



Replacing impulse sender Removal

Unclasp the lock clasps.


Remove cap, rotor and dust cover.



CAUTION:


Remove vacuum unit and clasps.

The retaining screws have different lengths and if improperly placed can project and damage moving parts. Therefore always place the screws together with the component to which they belong.




Remove the screws securing the contact.

Remove the contact by pulling it carefully straight out.




VOLVO
109 173

Remove the screws retaining the impulse sender plate.




VOLVO
109 174

Remove snap ring and shims.




VOLVO
109 175

Lift off the armature and the small lock pin.




Use snap ring pliers to remove the snap ring.
Lift up the impulse sender and plate.




Remove three screws and replace impulse sender.

VOLVO
109 177




Installation

Attach the impulse sender to the plate.
The connector pins should be placed opposite above the attachment ear for the impulse sender plate.




Install impulse sender.
Secure it with the two screws.
Install snap ring.

VOLVO
109 179




Install the armature.
The slot should be opposite the ridge on the distributor shaft.
Fit the lock pin so that the lift faces the ridge on the distributor shaft.
Otherwise the lock pin may be sheared off.


VOLVO
109 180




Install shims and snap ring.




Reconnect the wire connector and tighten the screw.



Install clasps and vacuum unit.



Install dust cover, rotor and cap.




VOLVO
109 252

Check distributor

Rotate the distributor shaft several turns in both directions.

It should rotate freely and without any noise or seizure.

The only resistance which may occur is the little stiffness caused by the magnet in the impulse sender when the teeth pass each other.



1. Primary connection 2. Attaching screw 3. Vacuum regulator

Installing distributor

Install distributor, rotor pointing same way as when removed.

Press the distributor into place. The rotor will turn when the gears engage. The distributor is in place when it is down approx. $3/16'' = 5 \text{ mm}$ and the rotor cannot be turned.

Reconnect distributor wire and high tension leads. Timing: 1-3-4-2.

Start the engine and set the timing.

(If the engine does not start, turn the distributor until it starts.)




Timing

Op. No. 34279

Connect tachometer and timing light. Start engine.

Turn the distributor to adjust the timing. Set timing at 5° BTDC at 600–800 rpm, vacuum hose disconnected.

Stop engine. Disconnect tachometer and timing light. Reconnect the vacuum hose at the distributor vacuum unit.



Lubricating distributor


The only lubrication permitted is applying a few drops of oil on the felt wick in the center of the rotor shaft.

Be careful, not to splash any oil on the impulse sender.

Use oil Bosch 01 V2 or similar.


start here

Check of breakerless ignition system



Group 35


Lights




Replacing Sealed Beam headlamps

Op. No. 35121


Turn 1/2 turn to remove the plastic screws.
Remove the headlight rim.



Turn the chromed ring slightly counter-clockwise.
Remove the chromed ring and lift out the headlamp unit.
Disconnect the socket contact.




Reconnect socket contact, install headlamp unit,
chromed ring and rim.



Headlight alignment

Op. No. 35102

Use the two screws to adjust the headlight alignment.




VOLVO
109 253

Replacing lens or bulbs in front turn signal lights


Op. No. 36130

Remove the screws retaining the lens.
Lift out the lens and replace bulb (or lens, whichever applicable)



VOLVO
109 254

Re-install lens.




VOLVO
109 255

Replacing lens or bulb for tail light

Op. No. 36132

Remove the screws retaining the lens. Lift out the lens and replace bulb (or lens, whichever applicable).




VOLVO
109 256

Check that the gasket is correctly positioned.
Re-install the lens.

Group 36

Standard Electrical Equipment



Replacing ignition switch

Op. No. 34002

Remove noise insulation panel and center side panel. Disconnect the terminal block for the ignition switch. Use a stubby screwdriver to remove the ignition switch.

Attach the new ignition switch.
Connect the terminal block.
Re-install panels.



Replacing turn signal switch


Op. No. 36108.

Remove the two casings round the steering column. Remove the two retaining screws. Transfer the wires to the new switch. Restore.

Replacing flasher unit

Op. No. 36102

Remove left side panel. Pull out the flasher unit from the terminal block. Install the new flasher unit and restore.




Replacing horn

Op. No. 36202

Disconnect the battery ground cable. Turn and lift off the lock pins. Remove the grille. Disconnect the wires at the horns. Remove the horns.

Install the horns.
Attach the wires as shown.
Install the grille and reconnect the battery ground cable.



Replacing control relays

Replace headlight relay = Op. No. 36502
Disconnect the battery ground cable.
Disconnect the relay from the relay panel.
Transfer terminal block and wires to the new relay.

Install the new relay. Reconnect the battery ground cable.



Replacing dimmer switch

Op. No. 36108

Remove the two casings round the steering column.
Remove the two retaining screws. Transfer the wires to the new switch. Reinstall the casings round the steering column.




Replacing light switch

Op. No. 36403

Disconnect the defroster hose from the defroster outlet.
Remove the screws retaining the defroster outlet.
Pull out the switch handle.
Lift out the defroster outlet.
Remove the nut and lift out the switch.


Disconnect the switch from the terminal block.
Connect the new switch.
Install switch, defroster outlet, switch handle and defroster hose.



Replacing wiper unit

Op. No. 36302 = replace wiper motor

Op. No. 36320 = replace wiper assembly




Removal

1. Disconnect the battery ground cable.
Remove the side panel.
Remove the panel under the dashboard.
2. Remove the defroster hoses.
Remove the glove box.
3. Remove the wiper arms.
Disconnect the wiper assembly and lift it out through the glove box opening.

Installation

1. Install the wiper assembly.
Remove the device securing the wiper assembly at transport and handling.
2. Install: glove box
defroster hoses
side panels
panel under dashboard
3. Install the wiper arms.
Reconnect the battery ground cable.
Check function.



1. Wiper motor

Tail gate window wiper, 245


Op. No. 36366 = replace

Disconnect the battery ground cable. Remove the panel on the inside of the tail gate.

Remove the retaining screws for the wiper motor protection plate.

Disconnect the link arm at the wiper motor. Fold the protection plate aside and lift out the wiper motor.

Mark the wires, and disconnect them at the wiper motor.



VOLVO
116 496

Replacing brushes

Fold the retaining bracket aside.

Unhook the brush springs.

Remove the brushes from the brush holders. Observe care not to damage the brush holders.

Install the new brushes.

Hook on the brush spring.

Installation

Reconnect the wires to the motor.

Attach motor and protection plate.

Reconnect the link arm to the wiper motor. Install the protection plate retaining screws.


Install the panel on the inside of the tail gate.

Reconnect the battery ground cable.

Replacing Bulb Failure Warning Light

Op. No. 36504

1. Disconnect the connector at the Sensor Unit.
2. Remove the Sensor Unit.
3. Install the replacement Sensor Unit.
4. Re-connect the connector to the Sensor Unit.
5. Check the function of the replacement unit.



VOLVO
116 497

Bulb Failure Warning Light, check

NOTE: The Bulb Failure Warning light may come on if the connected bulbs current draw is distorted. A short indication may sometimes occur, when the headlight is switched on, depending on variations in "starting" time for the bulbs.

1. Switch on the ignition.
The warning light should come on.
If the warning light does not come on, it is defective.
2. Start the engine.
The warning light should go out.
The Bulb Failure Warning light and the charging control light simultaneously: the alternator does not function.
The Bulb Failure Warning light is on after the charging control light has gone out: the Sensor is defective.
NOTE: the light switch should be pushed in and the brake pedal not actuated during the test.
3. Switch on the headlight lower beam.
The warning light should be out.
The Bulb Failure Warning light is on, but all bulbs for lower beam, parking light, tail light etc are functioning: the Sensor is defective.
4. Switch off the headlight lower beam.
5. Remove fuse No. 11 or 12.
The warning light should come on. If not, the Sensor is defective.
Re-connect the fuse.
6. Switch off the light.
7. Depress the brake pedal.
The warning light should be out. If it comes on and both brake lights function, it is defective.
8. Switch off the ignition.

Group 38

Instruments

Testing speedometer with odometer

If speedometer or odometer is not functioning, the reason may be a fault in instrument or speedometer cable or the worm gear in the transmission, or in the cable.

Check following:

If the speedometer functions while the odometer does not, or vice-versa, the instrument is defective and should be replaced. No attempt should be made to repair the instrument.

When both speedometer and odometer stop functioning, the fault is probably in the speedometer cable or the worm gear. Disconnect the speedometer cable from the instrument and see if it can be rotated. If it can, means it has broken from the worm gear. Check the cable and the drive at the transmission.


Check the drive couplings rotate easily. If it jams, the instrument should also be replaced.

The speedometer can be checked by running it at different speeds. The following values should then apply:

Speed of drive couplings:

Speedometer reading:

500	1000	1750	rpm
31.5±2.5	60.5±2.5	104.5±2.5	Mph



Speedometer and mileometer

YOLVO
108 709


Testing speedometer cable

It is most important that the speedometer cable is correctly fitted if the speedometer is to function

without trouble. It is vitally important that the cable is not bent too sharply. At no point must the radius of a bend be less than 100 mm (4"). If it is less than this, vibration and noise can occur in the instrument. The drive couplings must run true in the outer casing of the cable. This is checked with the cable rotating.

Testing temperature gauge

If the temperature gauge is faulty, the faulty component (sensor, indicating instrument or voltage regulator) must first be traced and then the fault remedied. In order to trace the faulty component, two or possibly three resistors are required, one or two at 40 ohms and one at 282 ohms.



YOLVO
108 709

Temperature gauge

Trouble shoot as follows:

First disconnect the electric cable from the temperature sensor and then connect up the 282 ohm resistor between cable and ground.

With the ignition switched on, the pointer on the indicating instrument should be at the beginning of the green field (=122°F). Instead of the 282 ohm resistor, then connect the 40 ohm resistor. The pointer on the indicating instrument should be at the beginning of the red field (248°F). With correct indicating instrument function, the sensor is defective and should be replaced.


NOTE: The sensor cable must **never** be wired directly to ground since it would overheat and ruin the instrument.

If the instrument gives incorrect reading, the fault is either in the indicating instrument or the voltage regulator.

In order to decide where the fault lies, disconnect the fuel gauge sender wire from the sender and connect a resistance of 40 ohms between wire and ground.

If the fuel gauge now shows a full tank, the fault must be in the indicating instrument of the temperature gauge, which must be replaced. If, on the other hand, the temperature gauge and fuel gauge give the same, but incorrect, reading, then the voltage regulator must be defective and should be replaced.

Testing removed temperature sensor




Sensor for temperature gauge

The sensor is checked by heating it and reading resistance and temperature.

(NOTE: The resistance may deviate $\pm 10\%$.)


Temperature	50	100	120	C°
	122	212	248	F°
Resistance	282	60	40	ohms



Wiring diagram for checking temperature gauge or fuel gauge indicating instrument

Testing fuel gauge

The fuel gauge is checked the same way as the temperature gauge.




Fuel gauge

Testing removed fuel gauge sender

The sender is checked with an ohmmeter wired the contact unit for the electric cable and ground. The following resistance values should be obtained if the sender is functioning correctly:

Position	Resistance in ohms		
A	282 \pm 48	C	98 \pm 14
B	223 \pm 26,5	D	40 \pm 5



Checking fuel gauge sender

VOLVO 108714




VOLVO
11R 49F

Replacing instrument cluster

Op. No. 38130

1. Remove the covers round the steering column.
2. Remove the bracket retaining screws.
Allow the bracket to slip down on the steering column.
Remove the retaining screws for the instrument cluster.
3. Disconnect speedometer cable.
4. Grip the reverse side of the speedometer and press the instrument up-out until the snap lock at the instruments upper edge releases.
5. Lift out the instrument and disconnect the terminal block on the reverse side.




VOLVO
107 345

Replacing tachometer (or blind cover)

Op. No. 38171 (instrument cluster removed)

1. (Remove instrument cluster, see above)
2. Remove three retaining screws.
3. Carefully remove the instrument. The terminals can easily be damaged.
4. Install tachometer (or cover) as shown.




VOLVO
107 389

Replacing speedometer assembly

Op. No. 38114

1. Remove instrument cluster, see above.
2. Remove tachometer or blind cover.
3. Remove three speedometer retaining screws.
4. Carefully remove the instrument.
Install as shown.




VOLVO
105 739

Combined instrument, reverse side

Replacing instrument plate ("printed circuit")

Op. No. 38109 (cluster removed).

1. (Remove instrument cluster, see above)
2. Remove tachometer (or blind cover)
3. Remove speedometer.
4. Remove three plate retaining screws.
5. Carefully remove the plate, not damaging temperature of fuel gauge.



Replacing fuel gauge sending unit

Op. No. 24508

1. Disconnect the battery ground cable.
2. Unfold the mat in the luggage compartment.
3. Remove cover and disconnect ground wire.
4. Disconnect the wire at the sending unit terminal.
5. Disconnect the return hose at the sending unit.
6. Disconnect and move aside the breather hose.
7. Use tool 9995016 to remove the sending unit.
8. Install the new sending unit with a new gasket.
9. Installation is opposite order.


Tool 9995016 for replacing fuel gauge sending unit.



Replacing clock

Op. No. 38124


1. Disconnect the battery ground cable.
2. Disconnect the control panel and pull it out.
3. Remove the impact guard by pushing it down.
4. Remove two screws.
5. Lift out defroster outlet and clock. Mark the wires before disconnecting.
6. Remove two retaining screws. Replace clock.
7. Installation is opposite order.



Replacing temperature gauge/fuel gauge

Op. No. 38114

1. Remove instrument cluster, Op. No. 38130.
2. Remove tachometer (or blind cover).
3. Remove speedometer.
4. Remove instrument.
5. Remove two retaining nuts on the instrument plate reverse side.
6. Remove the gauge.
7. Install as shown.



Replacing voltage stabilizer

Op. No. 38161

1. Pull straight out so that the three pins come loose from their retainers.

Replacing indicator light bulbs


1. The bulb holders come loose by pressing in the two retaining hooks and then pulling straight out.
2. Pull the bulb straight out.

Replacing temperature sender unit

Op. No. 38230


1. Drain approx. 2 quarts of coolant.
2. Disconnect the wire at the sender unit.
3. Screw out the sender and replace it.
4. Installation is opposite order.

Spare Parts Illustration



VOLVO PARTS
1 030 13053

Spare Parts Illustration



Section 3


Electrical System, Instruments

Description and theory of operation

Group 31: Battery	1
Group 32: Alternator Bosch	1
Group 33: Starter Motor	3
Group 34: Ignition System	
Breakerless Electronic Ignition System	4
Group 36: Standard Electric Equipment	6
Group 38: Instruments	11

Group 31

Battery




VOLVO
115 898

The battery is located front left in the engine compartment. Two ground cables connect to engine and body.

Group 32

Alternator, Bosch



VOLVO
185 227


1. Plus diode assembly
2. Magnetizing diodes
3. Brush holder
4. Rear bearing shield
5. Minus diodes

6. Stator
7. Motor
8. Front bearing shield
9. Fan
10. Pulley

The alternator is a three-phase, star connected alternating unit. The rectifier is built into the slip ring end shield and consists of six silicon diodes. Also housed in the slip ring end shield are three so-called magnetizing diodes, which feed the field via the voltage regulator.


An alternator has a rotating field coil (rotor) and a stationary main coil (stator). The rotor is a 12-pole clawpole type with the field coil fed across two slip rings.

Since the alternator output is self-limited (max. 55 amps), a simple regulator is used. It controls the voltage only.




Alternator

When the ignition is switched on, current flows through the charging warning lamp to terminal D+ on the voltage regulator. Via the regulator, the current is conducted through the field coil to ground.



Voltage regulator


- | | |
|--|---|
| 1. Regulator contact for lower control range | 3. Spring tensioner |
| 2. Regulator contact for upper control range | 4. Spring upper section: Steel spring
Lower section: Bi-metal spring |



Regulator

Alternator

If the voltage rises in spite of this, the armature on the voltage coil is pulled further down so that the upper control range contacts close. Thus the field coil is grounded at both ends which causes the voltage to drop rapidly. The cycle is repeated continuously so that the voltage is maintained constant.



Alternator output curve

A = amps
RM = alternator speed/minute

The alternator maximum output is 55 amps. Top speed is 15000 rpm.



Bosch Voltage Regulator



The voltage regulator is located on the wheel housing at a bracket behind the headlamp. It is a mechanical, single-pole voltage regulator with a lower contact, a movable contact and an upper contact. It is connected to the charging circuit by a three-pole plug. The regulator resistance is placed under a plate underneath the regulator. Temperature compensation is operated by a bimetallic spring which influences the spring tension so that the regulator receives lower regulating voltage at higher temperatures.

Group 33

Starter Motor



Starter motor, general arrangement


The starter motor is mounted on the flywheel housing on the left side of the engine. It is a 4-pole series-wound motor. The pinion on the starter motor armature shaft moves axially to engage the flywheel ring gear. The pinion is controlled by a solenoid.

Turning the ignition key to starting position cuts in the solenoid, causing the armature in the solenoid to be drawn in and the starter pinion to engage the ring gear on the engine flywheel. When the armature has moved a certain distance, the contacts for the main current close and the starter motor starts running.

Group 34

Ignition System

Breakerless Electronic Ignition System




Summary

Two main changes from the conventional ignition system:

1. The breaker points are replaced by an induction type **impulse sender**.
2. An **electronic module** has been added. It is wired between distributor and ignition coil. It amplifies the impulses before sending them on to the ignition coil.

Otherwise the design and function is the same as the conventional system.



Specific Function Information

1. Impulse sender

It is located in the distributor where the breaker points used to be.

Instead of closing and opening an electric circuit, the impulse sender opens and closes a magnetic circuit. This induces impulses in a coil (or magnetic pick-up).

The impulse sender consists of:

1. stator
2. coil (magnetic pick-up)
3. armature (rotor)
4. permanent magnet

Stator, coil and permanent magnet are connected to the distributor housing while the armature is connected to the distributor shaft.


Stator and armature have as many pole teeth as the engine has cylinders.

Note 1:

When using a distributor tester, also the electronic module must be connected in order to get a distributor output signal.

Note 2:


When making Cylinder Balance testing, most instruments require that a special adapter be used (or the engine will die).



VOLVO
115 248

The permanent magnet creates a magnetic field which goes through the stator. The magnetic circuit is **closed** when the pole teeth are opposite each other. The magnetic circuit is **open** when the pole teeth are separated. This means that the armature closes and opens the magnetic field while it is rotating. This generates current pulses in the distributor coil (magnetic pick-up).


Vacuum and centrifugal control of the timing is performed similar to the conventional distributor.



VOLVO
109 163

2. Electronic module

The electronic module is a solid state design with transistors. It amplifies the impulses from the impulse sender. It also controls the "dwell angle".



VOLVO
115 247

For 240 Series, a 1,0 Ω resistor is located on the firewall

The impulse received from the coil (magnetic pick-up) in the distributor is converted and reinforced in the electronic module and governs the output transistor which in turn governs the ignition coil primary circuit.


When the pole teeth are in front of each other, the module output transistor breaks the primary circuit, inducing secondary voltage in the coil to fire the spark plugs.

The pole teeth have a function similar to that of the cam lobes in a conventional distributor.

NOTE: The ignition coil is designed specifically for the breakerless solid state ignition system. It is identified by specifications and number only and cannot be replaced by other type coils.

Group 36

Standard Electrical Equipment




Turn signals

The switch is located to the left under the steering wheel.

Step 1 is lane change position. In maneuvers such as lane changing and overtaking, the driver can flash the turn signals by moving the turn signal lever to the first stop and hold it there. The lever returns to neutral when released.

Step 2 is "normal" turn signal position.



The turn signal pilot light on the panel is wired in parallel across the switch.



Hazard warning flasher

The turn signal lights are also used as hazard warning flashers. In that case they are engaged by a switch on the control panel and flash simultaneously.

The flasher relay is located to the left behind the control panel.



Ignition switch/steering wheel lock

It is located on the control panel, to the right of the steering column.

0 Locked position

Removing the key automatically locks the steering wheel.

I "Accessory" position

Permits operation of some electrical accessories.


II Driving position

III Starting position

As soon as the engine starts, release the key which automatically returns to the driving position.

If difficulty is experienced in turning the ignition key, turn the steering wheel slightly which will allow the steering lock to release.

Horns



The horns are located to the left behind the radiator grille.

One is low tone and the other high tone.

The horns are engaged by the steering wheel control.

Light relays

1. Stepping relay for upper/lower beams and headlight flashing.

Activated by moving the turn signal switch lever up.


Current to control the relay is normally furnished from the headlight switch.

When flashing the headlights the current is furnished from the terminal rack.

2. Relay for back-up lights.

Windshield wipers


The electric wiper motor is connected to the wiper arms by a system combining cables and links.



Windshield wiper unit

1. Wiper motor
2. Drive link
3. Parallel drive link

Headlight main switch



It is located on the control panel, to the left of the steering column.


Positions:

- All lights out
- Position lights front and rear on.
- Headlights and position lights on (A buzzer will sound if a front door is opened when the headlights are on).

Switching upper/lower beams

When headlight main switch is on, changing between upper and lower beams is achieved by moving the turn signal switch lever up and releasing.

When headlight main switch is off, the upper beam is on when the turn signal switch lever is moved up and until the lever is released.



Fuses

The fuse box is positioned in front of the left door pillar.


When replacing fuses, check that right "size" (amperage) is used.

Never use fuses of higher amperage. If one fuse often melts, leave the car to a shop for fault-tracing.

Reading downwards the fuses protect the following:

1. Rear window wiper/washer
245 only 8A
Cigarette lighter
2. Wiper/washer 16A
Horn
Blower
3. El. heated rear window 16A
Overdrive
4. Heater element, driver's seat 8A
Back-up light
Seat belt pilot light
5. Turn signals 5A
Instruments
Warning lights
Glove box light
6. Hazard warning 8A
Starter cut-out relay
Engine compartment light
7. Fuel pump 8A
Interior light, rear
Clock
8. Stop light 5A
Interior light
9. Ignition interlock 5A
Buzzer, seat belt
10. Instrument lighting 5A
11. Tail light, left 5A
Side marker light, rear and front (left)
License plate light, left (245, both lights)
12. Tail light, right 5A
Side marker light, front (right)
License plate light, right

Note: Fuse No. 9 controls the Seat Belt/Ignition Interlock System if the vehicle is so equipped. See instructions on removing fuse No. 9 to facilitate emergency starting.



Windshiel wiper motor, Electrolux


- | | |
|--------------------------|---------------------|
| 1. Cover | 6. Electric brushes |
| 2. Packing | 7. Stator |
| 3. Connection contact | 8. Rotor |
| 4. Contacts | 9. End |
| 5. Gear with contact bar | |

The wiper motor is permanent magnet type and provided with two plus brushes. These are connected, one at a time, giving two speeds:


- 34±4 rpm
- 55±5 rpm

The parking switch is housed in the gear housing.

The windshield wipers are controlled by a switch on the steering column right side.




Wiring diagram, windshield wiper motor, Electrolux



Wiring diagram, tail gate window wiper

a. To tail gate window washer



1. Wiper motor


VOLVO
104 397

Tail gate window wiper, 245

The wiper is operated by a single-speed electric motor, located in the tail gate door.

It is linked to the wiper arm and provided with a parking switch.

It is controlled by a switch on the control panel.



VOLVO
108 630

Window washer

The washer unit is located in the left front corner of the engine compartment. It is controlled by the wiper switch.


The washer comprises

- a pump driven by an electric motor
- fluid container
- hoses and jets


Pump and motor are in one unit, which is positioned in level with the fluid container bottom.

Group 38


Instruments



Combined instrument, front side



Combined instrument, reverse side



Speedometer and mileometer

The instrumentation consists of a combined instrument. It comprises a speedometer and trip meter, tachometer (certain models), temperature gauge, fuel gauge, warning lights for parking brake, brake circuit failure, oil pressure, battery charging, bulb failure warning and overdrive.


Also connected to the combined instrument is a voltage regulator which maintains constant voltage for the instrumentation.

Speedometer and Odometer

The speedometer and odometer are integrally built and driven by a drive line from a worm on the transmission output shaft.

The speedometer is of the eddy current type and mainly consists of a permanent magnet, a mounting disc and a rotor drum. The rotor drum is linked by a shaft to the gauge pointer. The shaft is also provided with a balance spring.

The odometer has a number of gears and registers up to 1 million km (600 000 miles). It is also provided with a trip meter. The ratio of the mileometer is so chosen that the drive line should rotate 640 times in order for the gauge to register 1 km.



VOLVO
107 345


Tachometer

Tachometer

The tachometer consists of a transistorized registration and amplifier unit and a rotational coil system.

The registration part senses the pulse frequency of the ignition coil. The amplifier part amplifies and conducts the pulses to the rotational coil system.

The rotational coil system consists of an annular shaped permanent magnet round which a coil is fitted. The coil is movable the length of the magnet and is linked to a shaft to which the tachometer gauge pointer is attached. When pulses from the amplifier are conducted through the coil, this forms a magnetic flow which coils the length of the permanent magnet. The rotational force is proportional to the current flow through the coil.




VOLVO
108 709

Temperature gauge


Temperature gauge, coolant

The temperature gauge is of the bimetal type and consists of sensor and registering instrument. The sensor is mounted on the engine and senses the coolant temperature. The registering instrument is included in the combined instrument.



Sensor for temperature gauge

VOLVO
107 366



VOLVO
107 347


Registering instrument, disassembled

1. Resistance wire
2. Bimetal spring
3. Pointer


The sensor, which is of the semi-conductive type, has a negative temperature coefficient, which means that its resistance drops in proportion to increased temperature.

The registering instrument consists of a bimetal spring connected to a pointer. A resistance wire, connected in series with the voltage stabilizer and sensor, is wound round the bimetal spring.


When the ignition is switched on, current flows from the voltage stabilizer through the resistance wire and the sensor to ground. When current passes the resistance wire, it heats up the metal spring and this causes the pointer to indicate on the gauge. The volume of the current passing through the resistance wire is in inverse proportion to the resistance of the sensor, and for this reason the gauge reading increases with increased engine temperature.



Fuel gauge



Sender for fuel gauge



Voltage stabilizer

Fuel gauge

The fuel gauge consists of a sender and indicating instrument. The sender in the fuel tank consists of a moving resistance, a lever and a float. The indicating instrument is of the same type as for the temperature gauge.

The function is exactly the same as for the temperature gauge, apart from the fact that the sender is mechanical. The amount of sender resistance engaged will depend on the amount of fuel in the tank and thereby the location of the float. In other words, an empty tank results in large sender resistance while a full tank produces minimum sender resistance. This has a corresponding effect on the indicating instrument.

Voltage stabilizer

The temperature and fuel gauges are powered by a voltage of 10 volts and are fed through a voltage stabilizer. This stabilizer contains a bimetal spring and a contact breaker. When the ignition is switched on, current flows through the stabilizer and out to the instruments. This heats the stabilizer bimetal spring which bends and thus breaks the circuit. As the spring cools down, it returns to its original position and the circuit is closed again. This cycle is repeated continuously. A regulated effect corresponding to a constant voltage of approx. 10 volts is thereby obtained. The breaking and marking of the circuit is not visible on the instruments due to their inertia. The stabilizer is mounted on the reverse side of the combined instrument.

The warning lights on this page should never light when driving.

These lights will light up when the ignition is turned on, before the engine is started. This is also to prove that the lights function. The light should go out after

the engine has started. (However, the parking brake reminder light will not go out until the parking brake is released.)

Oil pressure warning light (red)

If the light comes on during driving, the oil pressure is too low. Stop the engine immediately and check the engine oil level, see page 46. After hard driving, the light will come on occasionally when the engine is idling. This is normal, provided it goes out when the engine speed is increased.

The warning light for the oil pressure receives current via the ignition switch. It is grounded through a pressure sensitive valve on the engine. With the engine running and at normal pressure, the circuit through this light and ground is open. When the oil pressure drops below a pre-determined value, the pressure sensitive valve closes the circuit and the warning light is illuminated.

Brake failure warning light (red)

If the light comes on while driving and the brake pedal can be depressed further than normal, it is an indication that one of the brake circuits is out of function.

Should a fault arise in any of the two circuits of the hydraulic brake system, so that there is a pressure difference between the circuits of more than 8–10 kp/cm² (114–142 psi) when the brakes are applied, this actuates the valve and the warning light goes on. The warning lamp remains lighted until the fault in the brake system has been corrected and the warning valve re-set. Re, re-setting the warning valve, see Section 5, Brake, Group 52.

Alternator warning light (red)

If the light comes on when engine is running, check the alternator drive belt tension as soon as possible.

The alternator warning light lights up when the alternator voltage is lower than the battery voltage. As the alternator voltage rises and commences to charge the battery, the warning light goes out, indicating that the alternator is charging.

Parking brake reminder light

This light will be on when the parking brake (hand brake) is set. The parking brake lever is situated between the front seats.

The parking brake reminder light receives current via the ignition switch. When the parking brake is applied, the warning light is grounded by the switch. The warning lamp remains lighted as long as the parking brake is on.


Reminder light, EGR service

If the vehicle is equipped with an EGR (Exhaust Gas Recirculation) 15 000 mile service reminder light, as required by the U.S. Environmental Protection Agency, the light will come on at 15 000 mile intervals. This is a reminder to take your Volvo to the dealer to get the EGR valve serviced. The light will stay on until reset by the dealer.



Bulb failure warning light

The light comes on if any of the following lights is defective:

- one of the lower beams
- one of the tail lights
- one of the license plate lights
- one of the brake lights (when the brake pedal is depressed).



1
Reed Relay



VOLVO
108 721

Bulb failure warning lights

The system consists of a Reed relay and a warning light. It indicates if any of the bulbs for lower beam, tail light or stop light is out of order.

The indication is that the warning light comes on.

The Reed relay is located to the left under the dashboard, and the warning light is located in the combination instrument.

The Reed relay consists of a contact set, surrounded by three coil sets (one for lower beams, one for tail lights, one for stop lights).

Each coil set has two coils, one for left bulb, one for right bulb. The two coils are counteracting each other.

Function

When current flows through both coils in the coil set, that means that the bulbs on both sides are functioning, the two coils are counteracting each other and there is no actuation of the contacts, see I. But if the current flow through one of the coil ceases (the bulb is not functioning), the contacts are actuated and the warning light comes on, see II.

Indicator lights

Overdrive

The indicator light for the overdrive is connected between the switch for the overdrive and ground, and thus lights when the overdrive is engaged.


Turn signals

The indicator light for the turn signals flashes when the signals are engaged. It is wired across the switch for the signals.

Headlight

The light for the headlight upper beams comes on simultaneously with the full-beam headlights. It is wired parallel with the headlights at the relay.

Control panel




VOLVO
107 390

Rheostat for instrument light

The control panel contains a rheostat for the instrument panel lighting, cigarette lighter and switch with built-in control light for the electrically heated rear window and emergency warning flashers.

The control panel also contains the controls for the heating unit as well as a reminder light for the seat belts.



VOLVO
106 712

Electric clock, front and reverse

1. Battery connection
2. Bulb
3. Battery connection
4. Attaching screws

Clock

The clock is electric driven and located above the control panel.

Group 39

Wiring Diagrams

Index

Introduction

How to use the diagrams

Group 39

Group 38

Group 37

Group 36

Group 35

Group 34

Group 33

Group 32

Group 31

Group 30

Group 29

Group 28

Group 27

Group 26

Group 25

Group 24

Group 23

Group 22

Group 21

Group 20

Group 19

Group 18

Group 17

Group 16

Group 15

Group 14

Group 13

Group 12

Group 11

Group 10

Group 9

Group 8

Group 7

Group 6

Group 5

Group 4

Group 3

Group 2

Group 1

Traditional Wiring Diagram

Group 39

Wiring Diagrams

Index

How to use the diagrams

Group 24	CI Fuel Injection System	2
Group 32	Main Wiring Harness	3
Group 33	Starting Circuits	4
Group 34	Breakerless Electronic Ignition System	5
Group 35	Headlights	6
	Position Lights and Tail Lights	7
	Stop Lights	8
	Back-up Lights, Manual Transmission	10
	Back-up Lights, Automatic Transmission	11
	License Plate Light, 242/244	11
	License Plate Light, 245	12
	Bulb Failure Warning Light System	13
	Instrument Lights, Lights on Controls	14
	Glove Box Light	15
	Interior Light	16
	Interior Light, 245 rear	17
	Engine Compartment Light	18
Group 36	Turn Signals and Hazard Warning Flashers	19
	Horns	20
	Windshield Wiper and Washer	21
	245: Tail Gate Window Wiper and Washer	22
	Overdrive	23
	Cigarette Lighter	24
	Blower, Combined Unit	25
	Electrically heated Driver's Seat	26
	Electrically heated Rear Window, 242/244	27
	Electrically heated Tail Gate Window, 245	28
	Seat Belt Warning System, USA	29
	Seat Belt Warning System, Canada	30
Group 38	Instrument Cluster	31
	Clock	32

Traditional Wiring Diagram

How to use the diagrams

Start here

Introduction

The developments of the automotive electrical systems have continuously added new functions and components. Many of them have more than one duty to fill. The previously used wiring diagrams have thus been made increasingly complicated and difficult to use and understand.

The wiring diagrams contained herein represent a new method to present the electrical systems. They will make it very easy to find the actual system which will greatly simplify the use.

The wiring diagram has been broken down into circuits, each one dealing with a certain electrical function. Each electrical circuit is described on an inside page containing one left page and one opposite right page. Left is an "electrical road" showing joints and connections as well as normal operating circuits. Right page is shown the actual position of the circuit in the vehicle and position of components as well as marking of connections.

Except for some internal wirings, no symbols are used. Instead, a life-like illustration of the component is used, which should make it easy for anybody to understand the diagram.

See next page for further instructions.




How to use the diagrams

Use the Index to find the particular electrical function.
 Let us suggest you want to check the ignition system.
 In the Index you find "Breakerless Electronic Ignition System"
 page 5. Find the page.

Here you can see how the components are interconnected and their inside wiring.

Wire colors:	
SB	— black
GR	— gray
W	— white
R	— red
BR	— brown
Y	— yellow
NL	— blue
GN	— green

Approx wire sizes:	
0.75 mm ²	— 18 gauge
1.5	— 16
2.5	— 14
6.0	— 10
10.0	— 8
16.0	— 6



NOTE:

In those cases a fuse serves more than one circuit, it has been pointed out to simplify service diagnosis.

Example: Windshield Wiper/Washer does not operate


If *Blower* and/or *Horns* operate, it is obvious that the fault must be located *after* the fuse box.

If *Blower* and/or *Horns* *not* operate, the fault must be located before the fuse box.

Start here

System"

ystem




Here are shown the actual locations of the components and the routing of the wiring harness.

Here are shown the wire connections at the component.


The letters make it easy to go from left side to right side of the page.

CI Fuel Injection System




Fuse No 7:
Fuel Pump, CI System
+ Clock


Starting engine



Engine running

















Engine stalled (ignition on, but engine not running)





No 7:
Pump, CI System
ck


inition
(not running)




Main Wiring Harness




Starting Circuit




Starting Circuits








Starter Motor operating



A




B



C



D










Breakerless Electronic Ignition System



The current flows through the electronic module and the ignition coil is charged

The electronic module stops the current flow and the ignition coil discharges (sparks)






H

F

E


Headlights










Upper beam

Lower beam

Headlight flasher



A**B****C****D****E****F**

Position Lights and Tail Lights

Fuse No 11:



- Left Tail Light
- Left Front Position Light
- Rear Side Marker Lights
- Left License Plate Light

Fuse No 12:

- Right Tail Light
- Right Front Position Light
- Right License Plate Light
- Instrument Lights


Position Light

Side Marker Light





Light
Light

A



B




C


C

F

F




E





D







Stop Lights



Brake pedal depressed, lights ON









D




E

Back-up Lights, Automatic Transmission




**Gearshift Selector in "R",
ignition ON**






D




E





F

License Plate Light 242/244




Main light switch ON







License Plate Light, 245





Main Light Switch ON



A




B




E

C









D

Bulb Failure Warning Light System




Reed relay ON, bulb out (in lower beam, stop light, tail light front position light or license plate light (not 245).






Instruments Lights, Lights on Controls



Fuse No 12:


- Instrument Lights
- + Right Tail Light
- Right Front Position Light
- Right License Plate Light

Main light switch ON




tion Light
te Light




A




B



C



H



G

E


F

D


I

J

Glove Box Light






Glove Box Light ON




Interior Light

A




B


Interior Light




Doors closed,
interior light switch ON







Right door opened



Left door opened







C

D


Interior Light, 245, rear







Tail Gate closed,
Interior Light Switch ON






Tail Gate opened






Engine Compartment Light





Turn Signals and Hazard Warning Flashers






Fuse No 5:
Turn Signals
+ Instruments









Fuse No 6:
Hazard Warning Flashers
+ Engine Compartment Light
+ Rear Interior Light, 245

Left Turn Signal ON


Right Turn Signal ON

Hazard Warning Flashers ON






Horns




Horn Button depressed




Windshield Wipers and Washers



A




B




C




D




Windshield Wipers and Washers




Low speed











High speed




Washer








245: Tail Gate Window Wiper and Washer







Wiper and Washer ON

Wiper ON

Switch OFF
Circuit immediately
before parking







D

E


Overdrive




Overdrive ON





A



B



C




Y


R

Y


D




E




F







Cigarette Lighter




Lighter ON



Blower Combined Unit






Blower, Combined Unit




Low speed

Medium speed


High speed



Electrically Heated Drivers Seat




Electrically heated Driver's Seat




Heater element OFF



Heater element ON




A




B



C D




E




F


Electrically heated Rear Window, 242 / 244






Window Heater ON




A



B




C




D


Electrically heated Tail Gate Window, 245





Window Heater ON




A




B




C



D






Seat Belt Warning System USA









Seat belt buckled
Ignition ON
FASTEN SEAT BELT light on 4-8 seconds
no buzzer

Seat belt not buckled
Ignition ON
FASTEN SEAT BELT light on 4-8 seconds
Buzzer ON 4-8 seconds

Ignition key in ignition lock (any position)
Door Open
Key Warning buzzer sounds as long as door is open





Seat Belt Warning System Circuit




is open


Seat Belt Warning System Canada













Instrument Cluster




Instrument Cluster









Clock



Clock circuit energized



A



B

