

# VOLVO


## Service Manual

### Reconditioning

Section 4 (43)

Manual transmissions  
M 46, M 47, M 47 II  
including types J & P  
Overdrives

700



## Contents

	<b>Page</b>
<b>Foreword</b> .....	2
<b>Specifications</b> .....	4
<b>Special tools</b> .....	6
<b>M 46</b>	
Disassembling .....	10
Assembling .....	15
<b>M 47/M 47 II</b>	
Disassembling .....	29
Assembling .....	38
<b>Overdrive; Type J/Type P</b>	
Disassembling .....	55
Examining .....	63
Assembling .....	64
Checking oil pressures .....	71
<b>Components</b>	
M 46	
Foldout 1 .....	73
M 47	
Foldout 2 .....	75
M 47 II	
Foldout 3 .....	77
Overdrive Type J	
Foldout 4 .....	79
Overdrive Type P	
Foldout 5 .....	81



**Index page 83**

**Order number TP 30941/1**


We reserve the right to make alterations  
without prior notification.

## Foreword

### M 46 Transmission




Four-speed transmission with electrically-operated overdrive. Transmission housing of cast iron or aluminium. There are two types of overdrive, Type J and Type P.





#### Type J

Overdrive is engaged by a solenoid which changes the oil flow direction. The gear ratio is changed by a planetary gear.




#### Type P


Stronger than Type J and is used in combination with high-torque engines. Has no connection for speedometer cable.

**M 47/M 47 II Transmissions**

Five-speed transmission with the fifth gear assembly located in the rear extension. From 1986, the fifth gear synchronizer and gear wheel are located on the countershaft (previously on the main shaft). Hence the designation M 47 II. Both types have aluminium housings.

**M 47**

An additional shaft incorporating a shift fork engages/disengages the fifth gear. The fifth gear synchronizer and gear wheel are located on the main shaft.

**M 47 II**

The fifth gear shift fork is extended to reach the synchronizer and gear wheel on the countershaft.

Specifications

## Specifications

### Reduction ratios

	M 46	M 47/M 47 II
1st gear .....	4.03:1	4.03:1
2nd gear .....	2.16:1	2.16:1
3rd gear .....	1.37:1	1.37:1
4th gear .....	1:1	1:1
Overdrive (5th gear on M 47/M 47 II) .....	0.79:1	0.83:1 (M 47 II: 0.82:1)
Reverse .....	3.68:1	3.68:1

### Clearances

Reverse gear to shift fork .....	0.1–1.0 mm 0,004–0.04 in	0.1–1.0 mm 0.004–0.04 in
End float: input shaft .....	0.01–0.20 mm 0.0004–0.008 in	0.01–0.20 mm 0.0004–0.008 in 0.01–0.10 mm
countershaft .....	clearance 0.03 mm (0.0012 in) for pre- tension 0.05 mm (0.002 in)	
main shaft .....	0.01–0.20 mm (0.0004–0.008 in)	0.01–0.20 mm (0.0004–0.008 in)
5th gear synchronizer hub .....		0.01–0.20 mm (M47 only) (0.0004–0.008 in)

### Overdrive oil pressures

4th gear .....	approx 0.15 MPa (21 psi)
----------------	--------------------------

#### Overdrive engaged

	Type J
D 24 T, with asbestos-free friction linings .....	2.8–3.1 MPa (400–440 psi)
Gasoline turbo with asbestos-free friction linings .....	< 3.4 MPa (485 psi)
Gasoline turbo with old type friction linings .....	3.9–4.2 MPa (555–600 psi)
Remaining, with old type friction linings .....	3.7–4.0 MPa (525–570 psi)

#### Type P

All .....	2,8–3,1 MPa (400–440 psi)
-----------	---------------------------

### Lubricant

Type .....	*ATF type F or G
Oil capacity, M 46 .....	2.3 litre (2.4 US qt)
M 47 .....	1.3 litre (1.35 US qt)

\* In case of complaints use Volvo Thermal Oil, P/N 1161243-3. Volvo Thermal Oil should only be used for vehicles driven in areas where the temperature seldom drops below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ) or for high-mileage vehicles such as Taxis.

**Tightening torques**

	Nm	ft lb
Bell housing bolts .....	35-50	25-35
Bolts for rear cover (shift assembly) .....	35-50	25-35
Bolts for transmission cover .....	15-25	10-20
Bolt for countershaft, M 47/M47 II .....	35-45	25-30
Drive flange nuts, M 47, M 16 .....	70-90	50-65
M 20 .....	90-110	65-80
M 46 .....	165-180	120-135
Nut for rear housing M 46 .....	12-18	9-13
Nut for 5th gear synchronizer, M 47 II .....	120	90


**Overdrive**

Plug for relief valve .....	22	16
Plug for filter .....	22	16
Plug for check valve .....	22	16
Oil pan bolts .....	10	7
Nuts on stud bolts, front housing .....	12	9
rear housing .....	12	9
Solenoid valve (solenoid) .....	50	40
Nuts for bearing holder .....	10	7
Plug, oil pressure gauge connection .....	15	11


Special tools

## Special tools

999	Description - use
1801-3	<b>Standard handle:</b> installing clutch housing seal
1845-0	<b>Press tool:</b> installing drive flange
2412-8	<b>Drift:</b> installing seal, bearing, output shaft in overdrive
2413-6	<b>Drift:</b> installing front bearing on M 47
2520-8	<b>Stand:</b> for fixture 5130
2709-7	<b>Puller:</b> removing overdrive
2806-1	<b>Drift:</b> installing bearing in holder for clutch unit
2834-3	<b>Gauge:</b> oil pressure
2835-0	<b>Centering shaft:</b> for planetary gear to output shaft
2836-8	<b>Plug wrench:</b> for plugs
2852-5	<b>Support:</b> installing synchronizer hub
2853-3	<b>Support:</b> removing synchronizer hub
2867-3	<b>Drift:</b> installing clutch housing seal
2985-3	<b>Wrench:</b> removing main shaft bearing
2986-1	<b>Drift:</b> installing countershaft bearing
5058-6	<b>Puller:</b> removing main shaft bearing
5064-4	<b>Drift:</b> installing seal in rear housing
5069-3	<b>Puller:</b> seal
5090-9	<b>Tube:</b> installing damper
5096-6	<b>Spacer:</b> 5th gear housing (B 28 tool, 4 pcs)
5103-0	<b>Drift:</b> removing bearing in holder for clutch unit
5130-3	<b>Fixture:</b> used with stand 2520 or 5154
5131-1	<b>Puller:</b> removing countershaft bearings
5154-7	<b>Puller bolt:</b> for 5058




1801




1845 141 601


1845




2412



2413




2520




132 034


2709



2806




2834




2835


134 321




2836




2852




2853




2867




2985




2986




5058




5064




5069




5090




5096




5103



5130



5131







5147




Special tools


999	Description – use
5148-4	Extension for 5058 (2 pcs)
5149-3	Wrench: for round drive flange
5154-3	Bench attachment: for fixture 5130
5172-5	Crow foot wrench: for solenoid valve
5177-4	Puller: front bearing on countershaft, aluminium housing
5180-8	Drift: installing bearing on countershaft, aluminium housing
5183-2	Puller: for relief valve
5210-3	Ring: installing rollers in one-way clutch
5261-6	Puller: removing front bearing on countershaft
5262-4	Puller: 5th gear synchronizer hub
5304-4	Puller: removing drive flange
5305-1	Ring: for 5262 on M 47 II
5306-9	Press tool: installing bearing on main shaft and 5th gear M 47/ M 47 II
5308-5	Drift: installing rear housing seal, overdrive
5973-6	Washer: support for 998 7693 synchronizer/gear M 47 II
5986-0	Shaft: disassembling 5th gear synchronizer/gear M 47 II
998	
7693-0	Puller: removing 5th gear housing M 47/M 47 II
9177-0	Torque gauge: measuring damper torque




5172 134 388




5177 130 018




5180 128 914




5183 134 382




5210 134 387




5261 138 472




5262




5304




5305




5306




5308




5973



5986




998 7693



9177

## A. Disassembling M 46


Special tools: 5130+2520 or 5154, 2709, 2853, 2985,  
5058, 5131, 5147, 5148 (2 pcs), 5177



116 886

A1


**Mount transmission on fixture 5130 on floor stand 2520 or bench support 5154**



141 857

A3

**Remove gear shift assembly**




138 283

A4

**Remove transmission cover and gasket**

A5

**Remove selector plate and return spring**  
Lift off washers, spring and ball.



A6


**Disconnect overdrive from intermediate housing**

If required: use puller 2709

A7

**Remove gear selector rod**

Tap out both lock pins.




A8

**Remove intermediate housing**

Remove gasket.

Collect adjusting shims.



A9

**Remove clutch fork and clutch release bearing**


Save spacer washer.

A10

**Remove clutch housing and gasket**

Save adjusting shims.

Tap pipe rearwards to loosen seal. Some pipes have a lock ring, remove it first.



A11

**Tap out lock pin (1)**

A12


**Remove selector shaft (2)**

A13

**Remove shift forks (3)**

A14

**Remove selector shaft seal (4)**




A15

**Remove outer races for countershaft bearings**

*Transmission with aluminum housing:*

Carefully tap shaft in both directions to enable puller 5177 to grip races.



A16


**Remove main shaft bearings**

Remove oil pump eccentric.

Remove lock ring and ring for main shaft bearing. Place tool 2985 between input shaft and front synchronizer.

Use puller 5058, two extensions 5148 and puller bolt 5147 to pull off bearing.

Remove bearing thrust washer but leave tool 2985 in position.




**Removing all shafts**

A17

**Remove input shaft and synchronizer ring**

Pull out shaft. If bearing sits tight in housing, leave tool 2985 in place and tap main shaft with a mallet.

**Note!** Make sure that front part of countershaft contacts bottom of housing.



A18

**Lift out main shaft**


First turn transmission.

A19

**Lift out countershaft**

Turn transmission back.

Use a plastic mallet to tap out rear bearing race. Remove shaft.




A20

**Remove reverse gear wheel and shaft**

Use a drift to push shaft rearwards.

A21

**Remove selector for reverse gear**




**Disassembling main shaft**

*Transmission equipped with damper:*

A22

**Press off washer, remove springs and brake ring.  
Remove 1st gear with synchronizer ring.**


Remove lock ring for synchronizer hubs.



A23

**Press off 1st–2nd synchronizer hub and 2nd gear  
wheel with synchronizer ring**


Use support 2853.



A24


**Press off 3rd–4th synchronizer hub and 3rd gear  
wheel**

Use suport 2853.




**Disassemble synchronizers**

A25



**Remove countershaft bearing**  
Use puller 5131.

A26



**Remove input shaft bearing**  
Use support 2853.

A27

A28


**Clean and examine all parts**

Wash all parts with solvent. Dry with compressed air.

Examine all parts. Replace worn or damaged parts and all seals and gaskets.

## B. Assembling M 46

Special tools: 1801, 2852, 2853, 2867, 2986, 5090, 5180, 5306



### Assembling main shaft


B1

#### Assemble both synchronizers

Place hub in operating sleeve.

3rd-4th gear synchronizer:

Three recesses in hub should align with the three bevelled teeth in operating sleeve.



B2

#### Install sliding keys (1) and springs (2)


Lock sliding keys ("dogs") with springs. Hook both springs to the same sliding key.

Install one spring counter-clockwise. Turn synchronizer over and install second spring, also counter-clockwise.

If spring is bent, free end must point away from hub.



Assembling






**B3**

**Oil main shaft. Install 3rd gear wheel and synchronizer.**  
**Press on 3 rd—4th gear synchronizer hub.**

**Note!** On some transmissions, the gear wheel has a needle bearing. Make sure that it is fitted.

Make sure synchronizer ring is facing correct way. Turn wear surface on synchronizer hub UP.

Use support **2852**.





**Invert shaft**

**B4**

**Oil shaft. Install 2nd gear wheel and synchronizer.**  
**Press on 1st—2nd gear synchronizer hub.**

Make sure synchronizer ring is fitted correctly.

Use support **2852**.



**B5**

**Install lock rings for both synchronizers**

*Transmission without damper:*

**B6**

**Install synchronizer ring and gear wheel for 1st gear**

*Transmission with damper:*

**B7**

**Install thrust washer (1), if applicable, synchronizer ring (2) and gear wheel (3) for 1st gear**

**B8**


**Assemble damper**

Oil parts. Position springs in brake ring and twist washer into brake ring.


**B9**

**Press damper (4) on main shaft**

Use a file to remove sharp edges. Use tube **5090** when pressing on damper.




B10



**Press both bearings on main shaft**

Use drift 2986.

**Note!** Two types of rear bearings. Check transmission serial number to see that correct bearing is used.



B11

**Press bearing on input shaft**

Use standard handle 1801 and support 2853.

B12


**Install lock ring on input shaft**

*For transmissions with cast iron housing: proceed to operation B22.*

*Operations B13–B21 only apply to transmissions with aluminium housing.*

**Determining thickness of countershaft shims**

*The countershaft should have a preload of 0.03–0.05 mm (0.0012–0.0020 in). If countershaft, countershaft bearing or rear end bearing was replaced, shim thickness must be determined.*



**Note!** Apply assembly paste to aluminium surfaces prior to installing bearings and shafts.

Part Number 1 161 006-0 Aerosol  
1 161 078-9 Can

B13


**Install countershaft in housing**

B14

**Install front bearing race for countershaft**

Use drift 5180 large end facing race. Let race protrude approx. 1 mm (0.04 in). It will take up correct position when installing clutch cover.

Assembling



B15

**Install clutch housing and gasket**

Torque to 35–50 Nm (25–35 ft lb).

B16

**Turn transmission so that rear end faces UP**

B17

**Install rear bearing race for countershaft**

Use drift **5180** small diameter facing rear bearing race. Make sure bearing has no play. Rotate shaft and tap until there is no play (shaft has light resistance).

B18

**Measure distance between outer bearing race for countershaft and housing end face including gasket**

Position gasket on end face. Use depth micrometer and note distance.

B19

**Calculate thickness of shim for countershaft**

Preload should be +0.03 to -0.05 mm. (+0.0012 to -0.0020 in)

**Example:**

	mm	in	mm	in
Distance bearing race to gasket face	1.79	0.0705	1.79	0.0705
Clearance/preload	-0.03	-0.0012	+0.05	+0.0020
	1.76	0.0693	1.84	0.0725

Choose shim 1.80 mm (0.0709 in). If possible, choose shim of thickness to obtain countershaft preload. Following shims are available:

P/N	mm	in
949048-3	0.05 mm	0.002 in
948298-5	0.10 mm	0.004 in
948299-3	0.15 mm	0.006 in
948300-9	0.35 mm	0.014 in
948301-7	0.50 mm	0.020 in
948302-5	0.70 mm	0.028 in
948303-3	1.00 mm	0.040 in


B20

**Remove clutch cover and gasket**


B21

**Remove countershaft**


Continue assembling transmission as described for transmission with cast iron housing. The only difference is installing countershaft and determining shim thickness, as described above.




138 620



138 288



128 893



128 919

**Installing shafts in transmission housing**

B22

**Install gear selector for reverse gear**

Install lock ring for shift fork.



B23

**Install reverse gear wheel and shaft**

B24

**Check/adjust position of reverse gear shaft**

Shaft end should be flush with housing or max. 0.05 mm (0.002 in) inside housing face. See left.



141 711

B25


**Check/adjust clearance between reverse gear wheel and shift fork**

Adjust by tapping shift fork bearing stud, using a drift. See right illustration.

Correct clearance: 0.1–1.0 mm (0.004–0.040 in).

B26

**Place countershaft in bottom of housing**



128 922

B27

**Place main shaft in housing**


First turn housing

**Installing main shaft rear bearing**

B28


**Install thrust washer (only transmissions without damper) and bearing with lock ring on main shaft**

Countershaft should be positioned in bearings.



141 654

Assembling



B29

**Press main shaft bearing into position**


Use press tool 5306.

Make sure gear teeth do not clash and become damaged when pressing on bearing.

B30

**Make sure lock ring on bearing contacts housing**

If required, tap press tool with a mallet until bearing positions correctly.



**Installing input shaft**

B31

**Position 4th gear synchronizer ring in synchronizer hub**



B32

**Grease and install roller bearing in input shaft**

B33

**Install input shaft, lift countershaft**

Tap bearing outer race with a mallet if bearing is stiff. Place countershaft bearings in position before input shaft.



B34

**Install outer races for countershaft**

Transmission with aluminium housing:

Use drift 5180.

Front bearing: large end of drift.


Rear bearing: small end of drift.

B35

**Grease and install seal in bell housing**

First check that tube bottoms.

Use drift **2687** and standard handle **1801**.



**Determining thickness for shim on input shaft**


Input shaft should have an end clearance of 0.01–0.20 mm (0.0004–0.0080 in). If bearing on input shaft or bell housing was replaced, shim thickness must be determined.

B36

**Measure distance between outer face of input shaft bearing and front face of transmission**

Make sure lock ring on bearing abuts housing.

Use depth micrometer and note reading.




B37

**Position gasket on clutch housing**


B38

**Measure distance between outside of gasket and bottom of bearing seat**

Note reading.



B39



**Calculate shim thickness for input shaft**


Permissible end play. 0.01–0.20 mm (0.0004–0.0080 in).

Example:

Distance:	mm	in
– Gasket face to bearing recess	5.80	0.2283
– Bearing to transm. housing	<u>–4.85</u>	<u>–0.1909</u>
	=0.95	=0.0374
Deduct end play	–0.01	–0.0004
	<u>to 0.20</u>	<u>to 0.0080</u>
Determined shim thickness:	=0.75	=0.0294
	to 0.94	to 0.0370
Select shim thickness	<u>0.90 mm</u>	<u>0.035 in</u>

Following shim thicknesses are available:

P/N	mm	in
3292838–4	0.25	0.010
948008–X	0.60	0.024
948009–6	0.75	0.030
948010–4	0.90	0.036
948011–2	1.00	0.040



**Installing clutch housing ("bell housing")**

B40

Grease transmission gasket face and install gasket

B41

Position shim in clutch housing

Apply grease to hold shim in position.

B42

Install clutch housing


Torque to 35–50 Nm (25–35 ft lb)

B43

Install clutch fork, spacer washer and clutch release bearing

Prior to installing, grease bearing sliding surface and ball joint.

Sparingly apply grease to splines. (Do not forget washer under ball joint.)




*Transmissions with aluminium housing: proceed to operation B46.*

Operation B44–B45 only apply to transmissions with cast iron housings.

### Determining thickness for shim on countershaft


End float should be 0.025–0.10 mm (0.001–0.004 in). If the countershaft, any of its bearings, or the rear case/intermediate housing have been replaced the shim thickness should be determined.



**B44**

#### Make sure bearing races are correctly positioned

Depress races while turning main shaft a couple of turns until bearing rollers have centered.



**B45**

#### Position gasket. Measure distance between countershaft outer bearing race and gasket face.

Use depth micrometer and note reading.

<b>Example:</b>	mm	in
Distance race to gasket face	1.68	0.0661
permitted end float	–0.025	–0.0001
	<u>to 0.10</u>	<u>to 0.0040</u>
	<b>=1.58</b>	<b>=0.0660</b>
	to 1.655	to 0.0621

Select shim thickness **1.65 mm**. (0.066 in)

Following shim thicknesses are available:

P/N	mm	in
949048–3	0.05	0.002
948298–5	0.10	0.004
948299–3	0.15	0.006
948300–9	0.35	0.014
948301–7	0.50	0.020
948302–5	0.70	0.028
948303–3	1.00	0.040



### Determining thickness for shim on main shaft


Main shaft end float should be 0.01–0.20 mm (0.0004–0.0080 in.). If a main shaft bearing or the intermediate section has been replaced, the shim thickness should be determined.

**B46**

**Position gasket. Measure distance between outer face of main shaft bearing and rear face of transmission housing**

Make sure bearing spacer ring abuts housing.


Use depth micrometer and note reading.



**B47**

**Measure distance between intermediate section contact face and bottom of bearing seat**

Note reading.



**B48**

**Calculate shim thickness**

Permitted end float: 0.01–0.20 mm (0.0004–0.0080 in).


Example:


	mm	in
– Face to seat	5.50	0.2165
– Bearing to gasket face	–4.46	–0.1756
	= 1.04	= 0.0409
Deduct end float	–0.01	–0.0004
	to 0.20	to 0.0329
	to 0.84	to 0.0405

Select shim thickness **1.00 mm** (0.040 in).

Following shim thicknesses are available:

	mm	in
948008-4	0.60	0.024
948009-6	0.75	0.030
948010-4	0.90	0.036
948011-2	1.00	0.040






### Installing intermediate section

B49

#### Install selector shaft seal in housing

Use a socket to depress seal.



B50

#### Install shift forks (1)

Make sure lugs face correctly.


B51

#### Install gear selector (2) and selector shaft (3)

Gear selector collar forwards, grooves in selector shaft facing UP.

B52


#### Install lock pin (4) in gear selector



B53

#### Install lock ring for bearing and oil pump cam with lock ring


Install key for cam in main shaft.



B54

#### Grease transmission rear face. Position gasket and shims for countershaft

Grease shims to hold them in position.




141 647

B55

**Position main shaft shims in intermediate section**


Use grease to hold shims in position.



141 646

B56

**Install intermediate section**




141 644

B57

**Install overdrive**

Torque bolts to 12 Nm (9 ft lb).



141 643

B58

**Install selector rod**

Grease and install rubber ring in joint. Use sleeve to lock pins.


B59

**Install selector bracket**

**Note:** Bolt-washer-spacer tube-washer.


Torque bolts for rear end.

Torque: 35–50 Nm (25–35 ft lb).



B60


**Install washers (1), selector plate (2) and return spring (3)**



B61

**Check function**

Move selector plate by hand to check that all gears can be engaged and disengaged.




B62

**Grease contact face and position gasket**

B63

**Install interlock ball and spring**



B64

**Install transmission cover**

Torque bolts to 15–25 Nm (11–20 ft lb).


B65

**Install reversing light (back-up light) switch**

Also install overdrive switch and attach wire from solenoid.

B66

**Check that all overdrive bolts are tight and that there are no leaks**




## C. Disassembling M 47, M 47 II


Special tools: 5130+2520 or 5154, 2853, 2985, 5058,  
5131, 5147, 5148, 5261, 5262, 5304, 5305, 5973, 5986

On M 47 II the 5th gear synchronizer is on the counter shaft. On the early version (M 47-1985) it is on the main shaft.

**M 47**



141 602



141 603

**M 47 II**

C1

Mount transmission on fixture 5130 on floor stand 2520 or bench support 5154

C2

Drain oil

C3

Remove transmission cover and gasket  
Remove selector plate.

C4

Remove selector plate

Lift off washers, spring and interlocking ball.

C5

Remove clutch fork


Save spacer washer. Remove release bearing.

C6


Remove clutch housing ("bell housing") and gasket

Save adjusting shims.


Tap pipe rearwards to loosen seal. Some pipes have a lock ring, remove it first.



138 307







138 308



138 309

Disassembling



C7

Remove gear selector bracket and selector rod

C8

Remove drive flange

Engage two gears to lock transmission, prior to loosening nut.

If drive flange is difficult to remove, use puller 5304. It fits both the round and three-armed drive flanges.

C9

Remove rear end cover and gasket

C10

Remove rear end cover seal

M 47 II: proceed to operation C22.

Operations C 11 to C 21 only refer to M 47.

Removing 5th gear, M 47

C11

Remove bolt, washer and shims for counter-shaft

Reinstall bolt, 5-6 turns, no washer.


C12

Pull off 5th gear housing

Use puller 998 7693-0


Note: Puller claws should be ground as shown. Remove gasket.

Remove selector shaft seal.



C13

**Remove thrust washer and roller bearing with washer**



C14


**Pull off gear wheel from countershaft**

Use universal puller.

C15

**Remove gear wheel with needle bearing, support ring and synchronizer ring from main shaft**

Remove long bolt from countershaft.



C16

**Tap out three pins (1)**


Support shafts to prevent them from bending when pins are removed.

C17

**Pull out selector shafts (2)**

C18

**Remove shift forks (3)**




C19

**Remove spring. Disassemble 5th gear synchronizer.**

Remove lock ring for hub.





C20


**Remove two upper screws retaining bearing holder**

C21

**Pull off hub**

Use puller 5262.  
Save adjusting shims.

Proceed to operation C32.



Operations C22 to C31 only apply to M 47 II.

**Removing 5th gear, M 47 II**

C22

**Remove bolt, washer and countershaft shims**

C23


**Pull off 5th gear housing**

Refit bolt with washer 5973. Tighten bolt by hand until it bottoms.

Use puller 998 7693 to pull off 5th gear housing.


**Note:** grind puller claws as shown.

Remove gasket and selector shaft seal.



C24

**Remove thrust washer and roller bearing with washer**



C25

**Tap out three pins (1)**

Support shafts to prevent them from bending when pins are removed.


C26

**Pull out selector shafts (2)**

C27

**Remove shift forks (3)**


C28



**Pull off 5th gear wheel**

Remove two upper bearing holder screws.  
Use puller 5262 and ring 5305.


C29



**Pull off 5th gear wheel and synchronizer**

Use universal puller, supported on bolt head.

C30



**Disassemble 5th gear wheel/synchronizer**

Clamp a box-end wrench in a vice. Place synchronizer nut in wrench.

Use shaft 5986 plus torque wrench to loosen nut.

**Note:** If nut comes loose at a lower torque than 30 Nm (22 ft lb), a **new nut** should be used when reassembling.


Dismantle parts.

C31


**Remove washer on 5th gear synchronizer hub**

This operation should only be performed if a part is to be replaced.

Use screwdriver to pry washer loose.



141 297




C32

**Pull out front countershaft bearing**

Use puller **5261**.


Insert puller claws between rollers, pull out spindle to expand puller and pull out bearing.



C33

**Remove bearing holder from rear face**

Save adjusting shims.




C34

**Remove rear main shaft bearing**

Position support **2985** between input shaft and front synchronizer ring. Remove lock ring and bearing.

Use puller **5058** (without spindle), extension **5248** and puller bolt **5147**.




**Removing all shafts**

C35

**Remove input shaft with synchronizer ring**

Pull out shaft. If bearing is hard to remove leave support **2985** in position and tap main shaft with a mallet.

**Note:** Make sure that front part of countershaft abuts bottom of housing.



C36


**Remove main shaft**

Turn transmission and remove main shaft.

C37

**Remove countershaft**

Turn transmission back. Tap out rear bearing race with a plastic mallet. Remove countershaft.




C38

**Remove reverse gear and shaft**

Use a drift to force shaft rearwards.

C39

**Remove reverse gear shift fork**




**Disassembling main shaft**

*Transmission with damper:*

C40

**Press off washer. Remove springs and brake ring**




C41

**Remove thrust washer and 1st gear wheel with synchronizer ring**

Remove lock rings for synchronizer hubs.


Disassembling



C42

**Press off 1st—2nd synchronizer hub and 2nd gear wheel with synchronizer ring**


Use support 2853.



C43


**Press off 3rd—4th synchronizer hub and 3rd gear wheel.**

Use support 2853.



C44

**Disassemble both synchronizers**




C45

**Remove bearing on countershaft**

Use puller 5131.

141 713


C46



**Remove input shaft bearing**

Use support 2853.

C47



**Remove bearing races from 5th gear housing**

Use brass drift.

C48


**Clean and check**

Clean all parts in solvent. Dry with compressed air.

Check all parts. Replace all worn or damaged parts and all gaskets and seals.

### D. Assembling M 47/M 47 II

Special tools: 1801, 2413, 2852, 2853, 2867, 2985, 5064, 5090, 5096, 5306, 5986, 9177



#### Assembling main shaft

D1

#### Assemble both synchronizers

Place hub in operating sleeve. 3rd-4th gear synchronizer: Three recesses in hub should align with three bevelled teeth in operating sleeve.


D2

#### Install sliding keys (1) and springs (2)

Lock sliding keys ("dogs") with springs. Hook both springs to the same sliding key.

Install one spring counter-clockwise. Turn synchronizer over and install second spring, also counter-clockwise.

If spring is bent, free end must point away from hub.




D3

**Oil main shaft. Install 3rd gear wheel and synchronizer ring. Press on 3rd-4th gear synchronizer hub.**

Make sure synchronizer ring is facing correct way.

Turn wear surface on synchronizer hub UP. Use support 2852.



**Invert shaft**


D4

**Oil shaft. Install 2nd gear wheel and synchronizer ring. Press on 1st-2nd gear synchronizer hub.**

Make sure synchronizer ring is fitted correctly. Use support 2852.

D5


**Install lock rings for both synchronizers**



*Transmission without damper:*


D6

**Install synchronizer ring and gear wheel for 1st gear and thrust washer**





Assembling



Transmission with damper:

D7

Install thrust washer (1) if applicable, synchronizer ring (2) and 1st gear wheel (3)

D8


Assemble damper

Oil parts. Position springs in brake ring and twist washer into brake ring.

D9

Press damper (4) on main shaft


Use a file to remove sharp edges. Use 5090 to press on damper.



D10

Press rear bearing on countershaft

Use drift 2413.




D11

Press bearing on input shaft

Use standard handle 1801 and support 2853.

D12

Install lock ring on input shaft



**Installing shafts**

**Note:** Apply assembly paste to aluminium surfaces prior to installing bearings and shafts.

Part Number 1 161 006-9 Aerosol  
1 161 078-9 Can

D13

**Position reverse gear shift fork**

Install lock ring.

D14

**Install reverse gear and shaft**

D15

**Check/adjust position of reverse gear**



Shaft end should be flush with housing or max. 0.05 mm (0.002 in) below housing face.

D16

**Check/adjust clearance between reverse gear wheel and shift fork**

Adjust by tapping shift fork bearing stud, with a drift.  
Correct clearance: 0.1–1.0 mm (0.004–0.040 in).

M 47: proceed to operation D 22.



Operations D 17 to D 21 only apply to M 47 II.

**Assembling 5th gear synchronizer and gear wheel**

D17

**Fit washer to 5th gear synchronizer hub**

Use drift 2413. First position spring counter-clockwise in hub.

D18


**Assemble hub and operating sleeve**

Three recesses in hub should align with three bevelled teeth in operating sleeve. Hub washer and bevelled part of operating sleeve should face same direction.

D19

**Install sliding keys (1) and spring (2)**

The two springs should hook on to the same sliding key. Position spring counter-clockwise as shown in illustration.




141 296

D20

**Assemble shaft, needle bearing, gear wheel and synchronizer**

Bevelled edge of sleeve should face gear wheel.  
Install nut finger tight.



141 304


D21

**Torque nut**

Clamp a 42 mm box-end wrench in a vice. Place nut in box-end wrench. Use shaft **5986** and torque wrench.

**Note:** During tightening, torque should be 40–80 Nm (30–60 ft lb). If below, replace nut.

Torque: 120 Nm (88 ft lb).




D22

**Place countershaft in bottom of housing**

D23

**Place main shaft in housing**

First turn housing.




**Installing rear bearing on main shaft**


D24

**Position bearing with lock ring on main shaft**

Countershaft should lie in bearing recesses.



D25



**Press main shaft bearing into position**


Use press tool 5306.

Take care not to damage gear teeth when pressing bearing into position.

D26

**Make sure bearing lock ring abuts housing**

If necessary, tap press tool with a mallet until bearing seats correctly.



D27


**Install rear countershaft bearing race**

Use drift 2413.

**Note:** Top of race must be below housing face. Race will take correct position when cage is installed.

**Determining thickness of main shaft shims**

Main shaft end float should be 0.01–0.20 mm (0.0004–0.0080 in). If main shaft bearing or bearing holder has been replaced, shim thickness should be determined.



D28

**Measure distance between outer face of main shaft bearing and rear face of transmission housing**

Use depth micrometer and note reading.

Assembling

D29

**Measure distance between bearing holder contact face and bearing seat bottom**

Note reading.

D30

**Calculate thickness of shims for main shaft**

Permitted end float: 0.01–0.20 mm (0.0004–0.0080 in).

Example:

Distance:	mm	in
– Face to seat	5,50	0.2165
– Bearing to housing	–4,71	–0.1854
	= 0.79	= 0.0311
Deduct end float	–0.01	–0.0004
	to 0.20	to 0.0080
	= 0.59	= 0.0231
	to 0.78	to 0.0307

Select shim thickness **0,75 mm** (0.030 in)

Following shim thickness are available:

P/N	mm	in
3292838-4	0.25	0.010
948008-4	0.60	0.024
948009-6	0.75	0.030
948010-4	0.90	0.036
948011-2	1.00	0.040


D31

**Install bearing holder**


Torque to 15–25 Nm (11–20 ft lb)

**Note:** Do not interchange short bolts with long cover bolts


Tap bearing holder to seat bearing races.




138 328



138 288



138 329



138 830

*Transmissions with damper:*

D32

**Check torque for output shaft**

Use torque gauge 9177 and hold 1st gear wheel by hand.


Correct torque: **0.8–2.5 Nm** (7–22 in lb)

**M 47 II:** Proceed to operation D 37.

Operations D33 to D36 only refer to M 47.

### Installing 5th gear synchronizer hub Calculating shim thickness

Adjust bearing position to obtain a clearance of max 0.20 mm (0.008 in) to lock ring.



D33

Install original shim, as applicable

D35

Install lock ring

D36

#### Measure clearance between lock ring and hub

If clearance exceeds **0,20 mm, (0.008 in)**, remove hub and install shim.


#### Example:

Distance hub to lock ring : 0.25 mm (0.010 in)


Select shim thickness 0.15 mm (0.006 in)

Following shims are available:

P/N	mm	in
34615-5	0.10	0.004
120116-9	0.15	0.006
34614-8	0.35	0.014
947120-2	0.50	0.020



Proceed to operation D38.




Operation D37 only applies to M 47 II.

### Installing 5th gear wheel

D37

Press on spacer washer, 5th gear wheel and bearing race

Use press tool 5306 with thrust washer as support.



**Installing input shaft**

D38

Position 4th gear synchronizer ring in synchronizer hub

D39


Grease and install roller bearing in input shaft

D40

**Install input shaft, lift countershaft**

Tap bearing with a plastic mallet if it is difficult to move it.


Lift intermediate shaft before positioning input shaft.



D41

**Install front countershaft bearing**

Use drift 2413.



M 47 II; Proceed to operation D 45.

Operations D42 to D44 only refer to M47.

**Assembling 5th gear synchronizer, M 47**

D42

Install 3 sliding keys


D43

Position sleeve so that bevelled teeth align with sliding keys


D44

Install spring

Proceed to operation D47.



Operations D 45 to D 46 only refer to M 47 II



741 302

**Installing 5th gear and synchronizer, M 47 II**

D45


**Install 5th gear synchronizer and gear wheel on countershaft**

First pull out operating sleeve so that half of hub becomes visible. Then install synchronizer and gear wheel on countershaft.


D46

**Press on synchronizer and gear wheel**

Install bolt and washer. Tighten until bolt bottoms.



741 301



138 338

D47


**Install 1st-2nd and 3rd-4th gear selector fork, gear selector and selector shaft**

Make sure sliding lugs are positioned correctly. Gear selector lug should face forwards.

D48


**Install 5th gear shift fork, gear selector and selector shaft**

Gear selector lug should face forwards.



138 339






D49

**Install locking pins (3 ×)**

Grooves in selector shaft should face UP.

Pin in 5th gear shift fork should be flush with surface.  
Support 5th gear selector shaft when tapping pins into position.

*M 47 II: Proceed to operation D 53.*



*Operations D 50 to D 52 only refer to M 47.*

**Installing 5th gear wheel, M 47**

D50

Grease and install two needle bearings (1) and spacer (2) in 5th gear wheel

D51

Install synchronizer ring on synchronizer hub

D52


**Install both gear wheels**

Install bolt and washer on countershaft.

Pull bolt to press on large gear wheel.

Make sure large gear wheel is correctly positioned.


Remove bolt and washer.



D53

**Install washer, roller bearing and thrust washer**


Enclosed side of bearing should face rearwards.



D54

**Install bearing races and selector shaft seal in 5th gear housing**


Tap bearing races into position with a plastic mallet. Use a socket to install selector shaft seal.



D55

**Grease contact face, position gasket and install 5th gear housing**

Carefully tap 5th gear housing into position.



**Determining countershaft shim thickness**


Countershaft should have an end float of 0.01–0.10 mm (0.0004–0.0040 in). If countershaft, any of its bearings, or the rear case/intermediate housing have been replaced the shim thickness must be determined.

D56


**Install rear countershaft bearing M 47 II:**

Place support 2985 under nut when pressing bearing into position. Then install correct washer with old shim pack and tighten bearing to bottom.

**Note:** Make sure washer teeth align with gear teeth.



D57



**Attach 5th gear housing**

Use shift bracket bolts and 4 × 5096 (B28-tools) as spacers.

D58

**Install support 2985 on one of the bolts**

Torque bolts to 35–50 Nm (26–37 ft lb).

**Position dial indicator**

D59

**Push up and turn shaft to set front bearing. Calibrate dial indicator zero**

D60

**Lower and turn shaft to set rear bearing. Read dial indicator**

Note reading.  
(If no play exists, select thinner shim.)

D61

**Calculate thickness of countershaft shim**

Permitted end float: 0.01–0.10 mm. (0.004–0.0040 in).

Example:	mm	in
Measured clearance	0.25	0.0098
Existing shim pack	+0.55	+0.0220
Total clearance	= 0.80	= 0.0318
Deduct end float	-0.01 to 0.10	-0.0004 to 0.0040
Shim thickness	= 0.70 to 0.79	=0.0278 to 0.0314

Select shim thickness 0.75 mm (0.030 in).




Following shim thicknesses are available


P/N	mm	in
3294334-2	0.10	0.004
3294335-9	0.15	0.006
3294336-7	0.25	0.010
3204069-3	0.55	0.022
3204070-1	0.75	0.030

D62

**Install new shim pack, washer and a new self-locking bolt, or use thread locking compound 1161053-2**

Engage two gears to lock transmission. Torque to: 35–45 Nm (25–32 ft lb).





**Installing rear end cover**


D63

**Make sure vent hole is not blocked**

D64

**Install seal in rear end cover**

Grease and install output shaft seal. Use drift **5064**. Seal should be positioned **2,5 mm (0.1 in)** inside flange.



D65

**Grease housing face and position gasket**

D66


**Use two bolts to attach rear end cover**

D67

**Attach gear selector rod**


Grease and install rubber ring in joint. Use sleeve to lock pins.

D68



**Install selector bracket**

**Note:** Bolt – washer – spacer tube – washer. Torque bolts to **35–50 Nm (25–35 ft lb)**.



D69

**Install drive flange**

Torque nut to:

- Bolt M16 ..... **70–90 Nm (50–60 ft lb)**
- Bolt M20 ..... **90–110 Nm (65–80 ft lb)**


Engage two gears to lock transmission.

D70

**Grease and install seal in bell housing**

Make sure pipe is at bottom.

Use drift 2867 and standard handle 1801.



**Determining input shaft shim thickness**

Permitted end float: **0.01–0.20 mm.** (0.0004–0.0080 in). If input shaft, bearing on input shaft, or clutch housing has been replaced, shim thickness must be determined.

D71

**Position gasket on clutch housing**

D72

**Measure distance between gasket top and bearing seat bottom**

Note distance



D73


**Make sure bearing spacer washer abuts housing**

D74

**Measure distance between upper face of input shaft bearing and front face of transmission housing**

Use depth micrometer and note reading.





D75

**Calculate input shaft shim thickness**

Permitted end float: **0.01–0.20 mm.** (0.0004–0.0080 in).

**Example:**


Distance:	mm	in
– gasket face to bearing seat	5.80	0.2283
– bearing to housing	–4.85	–0.1909
	=0.95	=0.0374
Deduct end float	–0.01	–0.0004
	to 0.20	to 0.0080

Calculated shim thickness =0.75 to 0.94 =0.0294 to 0.0370

Select shim thickness **0.90 mm.** (0.036 in).

Following shim thicknesses are available:

P/N	mm	in
3292838-4	0.25	0.010
948008-8	0.60	0.024
948009-6	0.75	0.030
948010-4	0.90	0.036
948011-2	1.00	0.040




D76

**Grease transmission gasket face and position gasket**

D77

**Position shim in clutch housing**

Apply grease to hold shim in position.



D78

**Install bell housing**

Torque to **35–50 Nm** (25–35 ft lb).

D79

**Install clutch release fork, washer and release bearing**


First apply grease to bearing sliding surface and ball joint.

**Sparingly apply grease to splines.**

Do not forget to place washer beneath ball

D80


**Install sliding washers and selector plate**



D81


**Check function**

Move selector plate by hand to check that all gears can be engaged and disengaged.



D82

**Install interlock ball and spring**



D83

**Grease housing face and position gasket**

D84


**Install transmission cover**

Torque bolts to 15–25 Nm (11–20 ft lb).

## E. Disassembling Type J and Type P, overdrives


Special tools: 2836, 5069, 5103, 5149, 5172,  
5183, 5210, 5303, 5304, 5973,

Type J



141 607

Type P



141 162

### Disassembling


E1

Clamp overdrive rear end in a vice protected by soft jaws

E2

Remove solenoid valve

Use crow-foot wrench 5172. Disconnect ground wire.



5172

141 269

E3


Remove:

- bridges.
- front and rear housing nuts

**Note:** Last two nuts removed should be opposite each other. Loosen the nuts stepwise.

E4

Remove front housing assembly




141 308

E5

Remove:

- brake drum
- springs. Lift out clutch, thrust bearing and sun gear assembly.




141 260

Type P: Proceed to operation E7.



Disassembling



134 335


Operation E6 only applies to Type J. Overdrive.

E6

**Remove planetary gear assembly**

Replace planetary gear assembly if gears or carrier are damaged.

Proceed to operation E9.



141 258

Operations E7 to E8 only refer to Type P Overdrive.

E7

**Remove:**

- planetary gear carrier
- thrust washer


If one-way clutch or planetary gear carrier is to be replaced:

E8

**Pull off one-way clutch from planetary gear carrier**

Use universal type puller.  
Place washer 5973 under puller spindle.

Replace planetary gear assembly if damaged



141 298

**Disassembling front housing**


E9

Clamp overdrive front part in a vice protected by soft jaws

E10

**Remove:**

- oil pan and strainer
- pistons. Use pliers.




141 257

E11

**Remove oil filter plugs, check valve and relief valve**

Use plug wrench 2836. Tap plugs with a plastic mallet to facilitate removal.




E12

**Remove:**

1. Oil filter
2. Check valve and spring, ball and seat
3. Relief valve assembly. (If replacing, always use new type relief valve).


Examine relief valve piston. If scored, it will damage O-ring. Replace relief valve assembly.



E13

**Withdraw cylinder and relief valve seat**

Use extractor 5183.




E14


**Examine relief valve**

If engagement valve is slow or if overdrive slips on engagement, it is particularly important to check following.

Check valve seat. If there are signs of wear, replace relief valve assembly.




Disassembling



141 255

E15

Remove cylinder and pump piston




134 331

E16

Disassembling clutch assembly

Remove lock ring. Pull out sun gear and clutch disc from bearing carrier



134 329

E17

Remove lock ring. Tap out bearing from carrier.  
Use drift 5103.

Type P: Proceed to operation E22.

Operations E18 to E21 only refer to Type J.

Disassembling rear housing. Type J Overdrives


E18

Clamp overdrive rear housing in a vice protected by soft jaws

E19


Remove lock ring and one-way clutch oil slinger

Note: Turn one-way clutch in locking direction and make sure that outer ring does not slip on input shaft.



135 096


E20



**Remove one-way clutch**

Use ring 5210. Turn ring clockwise


E21



**Examine roller cage**

Invert ring with one-way clutch in it. Check to see if roller cage is oval. If so, replace with new type, Volvo P/N 1209726-7.


E22



**Disassemble one way clutch**

**Note** Illustrations show an early version of one-way clutch.

Replace any damaged parts.




If early type one-way clutch is fitted, replace it with new type: Volvo P/N 1209484-3. (Location of lock spring hole is new.) See illustration.

Proceed to operation E26

Type J/Type P, Overdrives

Disassembling



Operations E 22 to E 25 only refer to Type P.

**Disassembling rear housing, Type P, Overdrive**


Clamp overdrive rear housing in a vice protected by soft jaws

E23

Pry up oil slinger in two places to install puller 5069.


Place a socket on hub. Use a screwdriver to pry up oil slinger.

E24



**Modification to tool 5069**


Replace center bolt with a 40 mm long bolt, threaded along entire length. P/N 998 9709.



E25

Place drift 5103 (group 21 tool) in bottom of housing. Use puller 5069 to draw out oil slinger.

Remove roller cage.



E26

**Remove drive flange nut**

**Round drive flange:** Use wrench 5149 to hold.


**Three-arm drive flange:** Clamp drive flange in a vice.

**Note:** Use wrench 5303 when removing drive flange from vehicle.

E27


**Withdraw drive flange**

Use puller 5304 if required.




E28

**Remove oil seal with puller 5069.**



E29


**Press out output shaft**



E30


**Remove spacer sleeve**

(On Type J: speedometer drive gear.)



E31


**Withdraw output shaft bearing**



141 248

E32

**Tap out bearing from rear housing**  
(Only if bearing is to be replaced.) Use brass drift.



141 247

## F. Examining overdrive

### *Cleaning and checking*

**Check:**

- that control orifice drilling between relief valve and solenoid is free from dirt. If it is not possible to blow-clean, use a pointed matchstick. Do not attempt to clean the orifice with wire or its calibration may be impaired.
- that groove in front of ring gear in output shaft is thoroughly clean. (Dirt collects here as a result of centrifugal force.) Clean all parts and check carefully for signs of wear, cracks or other damage. Check following carefully:
  - that filter is undamaged
  - operating pistons for scores or wear
  - valves for wear
  - all gear wheels and bearings for cracks and wear.

**Check:**


- that clutch return spring is  $55.5 \pm 1.5$  mm (2.1852 0.060 in) long
- that springs are not misshaped or cracked
- brake ring for cracks, scores, wear etc.
- cone clutch for signs of burning or wear
- solenoid by means of a 12 volt battery and an Ammeter. Power consumption = 1.5–2.0A. Check movement of solenoid plunger.



## G. Assembling Type J and Type P overdrives

Special tools: 1845, 2412, 2806, 2834, 2835, 2836, 5149, 5172, 5210, 5308

Use new gaskets, O-rings and seals when assembling overdrive. Observe utmost cleanliness since the hydraulic system is very sensitive to dirt.




### Assembling rear housing

G1

Press bearing in rear housing


Use drift 2412.



Press on bearing on output shaft

G2

Use drift 2412.




Install spacer sleeve on output shaft

G3


(On Type J: speedometer drive gear.)

G4



**Press output shaft in rear housing**  
Use drift 2412.

G5



**Tap oil seal into rear housing**  
Use drift 5308.

*Type P: Proceed to operation G13.*

*Operations G6 to G12 only refer to Type J.*

*Before installing one-way clutch:*

G6

**Make sure thrust washer is correctly positioned**  
If thrust washer is replaced, make sure that it is correctly positioned. It should be 0.6 mm (0.024 in) above edge.



G7


**Correct thrust washers:**

- Use thickness 2.5 mm (0.1 in), P/N 380 715-3, for early version of output shaft, P/N 380 679-1 and P/N 1 232 105-5.
- Use thickness 3.8 mm (0.15 in), P/N 1 232 644-4, for output shaft P/N 1 232 646-3.

G8

**Install one-way clutch hub and roller cage with rollers**






G9

**Install oil slinger and lock ring**

Check that one-way clutch functions correctly.



G10

**Install drive flange**

Apply locking fluid, P/N 1 161 075-5, to splines. Be careful not to apply to seal.

Use press tool **1845** if required.


G11

**Install nut**

**Round** drive flange: use wrench **5149**.

**Three-arm** drive flange: clamp drive flange in a vice.

Torque to 175 Nm (130 ft lb).




G12

**Install planetary gear on output shaft**

Guide splines into carrier and one-way clutch hub. Use centering drift **2835**.

*Proceed to operation G 18.*



G13

*Operations G13 to G17 only apply to Type P.*

**Install drive flange**

Apply locking compound, P/N 1 161 075-5, to splines. Be careful not to apply to seal. Use press tool **1845** if required.

G14

**Install nut**

**Round** drive flange: use wrench **5149**.


**Three-arm** drive flange: clamp drive flange in a vice. Torque to 175 Nm (130 ft lb).

G15

**Position roller cage for one-way clutch**

Groove on roller cage should face UP.

Use a drift to tap in oil slinger.




G16

**Press one-way clutch hub on to planetary gear carrier**

Wipe off splines.

Bevelled edge on hub should face DOWN.


Use ring 5210 when pressing.



G17

**Install:**

- brass thrust washer
- planetary gear carrier




**Installing clutch assembly**

G18


**Press in bearing**

Use drift 2806. Attach lock ring



**Type P: Proceed to operation G 21.**

**Operations G 19 to G 21 only apply to Type J.**




**G19**

**Asbestos-free clutch linings in overdrive Type J for D 24 T**

From transmission serial number 1 208 438/107 770, the D24 T is equipped with asbestos-free linings in the overdrive. However, there are some D 24 T models with higher transmission serial numbers which have the old type friction linings, see below.

Engine	Transmission serial number	Overdrive Volvo P/N	Laycock Overdrive No	
D24T	1 208 438/107 770-108 305	1 208 478	115 970	With asbestos-free clutch linings
D24T	1 208 438/108 306-	1 208 478 or	115 970	With asbestos-free clutch linings
		1 208 282	115 925	With old type clutch linings

The asbestos-free material has improved friction properties, which make it possible to reduce overdrive oil pressure to 2.8–3.1 MPa (400–440 psi). The new clutch linings also have a larger area.



**380 910-0**

**1377039-1**

**G20**


**When overhauling**

For Turbo vehicles, clutch linings of the asbestos-free type (P/N 1 377 039-1) should be used, unless already used as shown in chart above.

When replacing clutch linings, the brake drum should also be replaced. P/N 380910-0.

(All Type P overdrives have asbestos-free clutch linings.)

G21



**Dry clutch in a warm place**

All moisture must be removed from the friction lining before the clutch is fitted to the front housing. When dry, oil lining with ATF type F or G.

G22



**Install:**

- sun gear
- clutch
- lock rings.

G23

**Install:**

- clutch assembly
- springs
- gasket between rear housing and brake drum. Make sure gasket is installed correctly.
- brake drum



**Assembling front housing**

*Prior to assembling, make sure front housing is carefully cleaned. The hydraulic system is very sensitive to dirt.*

G24

**Lubricate oil pump with ATF before fitting to front housing**


Make sure that the groove and bevel on the pump plunger are aligned with the recess for the pressure filter. This prevents knocking noise from pump.


G25

**Check non return valve seat for leakage**

Blow through the valve to check for leakage. If the leakage is slight place the seat and steel ball on a flat surface and tap the ball with a plastic mallet. Recheck.

If the leakage is large the valve seat is probably too oval and therefore should be replaced. Make sure when fitting the valve that the steel ball is positioned correctly.






**Install:**

1. Oil filter, gasket and plug.
2. Seat, ball, spring and plug for check valve. Make sure ball is positioned correctly.
3. Relief valve parts. Always use new type if piston is replaced. Install shims, if applicable.

**Note:** If new clutch linings of asbestos-free type have been installed, no shims should be fitted to the relief valve.


**Torque plugs**

Use plug wrench 2836 and torque to 22 Nm (16 ft lb).



**Install oil pan**

Install strainer and gasket.  
 Make sure magnet in oil pan is cleaned.  
 Torque bolts to 10 Nm (7 ft lb).



**Position clutch pistons in cylinders**

**Note:** As a running modification during the Spring of 1985, 4 mm longer clutch pistons with a Teflon ring on the outside of the O-ring for improved sealing, have been installed. Pistons with O-rings should be replaced by new type pistons with Teflon ring, P/N 1 377 041-7.


**Assemble rear and front housings**


**Note:** Make sure gasket fitted between brake drum and rear housing is installed.

Remove remains of old nylon washers from two upper bolts on rear housing. Install new nylon washers, small end towards rear housing. Torque nuts in stages to 12 Nm (9 ft lb).

**Install bridges**

Torque nuts to 10 Nm (7 ft lb).






**Install solenoid. Attach ground wire.**

Use crow-foot wrench **5172**.

Torque to 50 Nm (37 ft lb).

## H. Testing oil pressure

*Special tool: 2834*



The oil pressure can be checked when driving on test rollers or highway.

Remove plug or switch below control valve and connect test gauge **2834**.

Drive in 4th gear, overdrive disengaged, speed 70 km/h (45 mph). Pressure should be approx. 0.15 MPa (21 psi).

Engage overdrive. Pressure should increase to:

### Type J

D24T and gasoline Turbo	<b>Rebuilt with asbestos-free clutch linings</b>	<b>3.1–3.4 MPa (440–483 psi)</b>
----------------------------------	--	--------------------------------------

D24T	<b>Originally with asbestos-free clutch linings (overdrive P/N 115 970)</b>	<b>2.8–3.1 MPa (400–440 psi)</b>
------	---	--------------------------------------

Gasoline Turbo	<b>With old type clutch linings</b>	<b>3.9–4.2 MPa (554–596 psi)</b>
-------------------	---	--------------------------------------

Re- maining	<b>With old type clutch linings</b>	<b>3.7–4.0 MPa (525–568 psi)</b>
----------------	---	--------------------------------------

### Type P

All		<b>2.8–3.1 MPa (400–440 psi)</b>
-----	--	--------------------------------------

Disengage overdrive and check time for pressure reduction to 0.15 MPa (21 psi).

Time must not exceed 3 seconds.



**M 46 Transmission  
components**

(Fold-out 1)


### M 46 Transmission components

- 1 Needle bearing
- 2 2nd gear wheel
- 3 Synchronizer ring
- 4 Spring
- 5 Operating sleeve
- 6 Synchronizer hub
- 6a Washer
- 7 Sliding key ("dog")
- 8 Synchronizer ring
- 9 Lock ring
- 10 1st gear wheel
- 11 Damper
- 12 Spring
- 13 Brake cone
- 14 Drive flange
- 15 Needle bearing
- 16 Thrust washer (if not equipped with damper)
- 17 Sleeve
- 18 Input shaft
- 19 Needle bearing
- 20 Lock ring
- 21 Synchronizer ring
- 22 Spring
- 23 Operating sleeve
- 24 Synchronizer hub
- 25 Sliding key
- 26 Synchronizer ring
- 27 3rd gear wheel
- 28 Needle bearing
- 29 Main shaft
- 30 Lock ring
- 31 Intermediate shaft ("countershaft")
- 32 Reverse gear wheel
- 33 Stud shaft
- 34 Overdrive switch
- 35 Transmission (top) cover
- 36 Gasket
- 37 Spring
- 38 Selector plate
- 39 Pin
- 40 Engaging lug
- 41 Shift fork
- 42 Gear selector
- 43 Washer
- 44 Guide pin
- 45 Spring
- 46 Lock ring
- 47 Reverse gear selector
- 48 Selector shaft

- 49 Spring
  - 50 Interlocking ball
  - 51 Lock ring
  - 52 Ball bearing
  - 53 Shim, thicknesses
- | P/N       | mm   | in    |
|-----------|------|-------|
| 3292838-4 | 0.25 | 0.010 |
| 948008-8  | 0.60 | 0.024 |
| 948009-6  | 0.75 | 0.030 |
| 948010-4  | 0.90 | 0.036 |
| 948011-2  | 1.00 | 0.040 |

- 54 Roller bearing
  - 55 Magnetic debris plug
  - 56 Gasket
  - 57 Plug
  - 58 Transmission housing
  - 59 Gasket
  - 60 Stud shaft
  - 61 Roller bearing
  - 62 Shim, thicknesses
- | P/N      | mm   | in    |
|----------|------|-------|
| 949048-3 | 0.05 | 0.002 |
| 948298-5 | 0.10 | 0.004 |
| 948299-3 | 0.15 | 0.006 |
| 948300-9 | 0.35 | 0.014 |
| 948301-7 | 0.50 | 0.020 |
| 948302-5 | 0.70 | 0.028 |
| 948303-3 | 1.00 | 0.040 |

- 63 Seal
- 64 Ball bearing
- 65 Intermediate housing



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14

15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31

**M 47 Transmission  
components**

(Fold-out 2)

32  
33  
34  
35  
36  
37  
38

## M 47 Transmission components

- 1 Rear end cover
- 2 Seal
- 3 Top cover
- 4 Gasket
- 5 Spring
- 6 Selector plate
- 7 5th gear housing
- 8 Gasket
- 9 Roller bearing
- 10 Bearing outer race
- 11 Speedometer drive gear
- 12 Bearing outer race
- 13 Bearing inner race
- 14 Shim, thicknesses:

P/N	mm	in
3294334-2	0.10	0.004
3294335-9	0.15	0.006
3294336-7	0.25	0.010
3204069-3	0.55	0.022
3204070-1	0.75	0.030


- 15 Washer
- 16 Gear selector
- 17 Pin
- 18 Selector shaft
- 19 Shift fork
- 20 Reverse gear selector
- 21 Stud shaft
- 22 Shift fork
- 23 Gear selector
- 24 Engaging lug
- 25 Spring
- 26 Interlocking ball
- 27 Selector shaft
- 28 Sliding washer
- 29 Guide pin
- 30 Lock ring
- 31 Shim, thicknesses:

P/N	mm	in
3292838-4	0.25	0.010
948008-4	0.60	0.024
948009-6	0.75	0.030
948010-4	0.90	0.036
948011-2	1.00	0.040

- 32 Ball bearing
- 33 Roller bearing
- 34 Transmission housing
- 35 Gasket
- 36 Seal
- 37 Ball bearing
- 38 Shim, thicknesses:

P/N	mm	in
34615-5	0.10	0.004
120116-9	0.15	0.006
34614-8	0.35	0.014
947120-2	0.50	0.020

- 39 Bearing holder
- 40 Drive gear
- 41 Roller bearing
- 42 Intermediate shaft
- 43 Reverse gear wheel
- 44 Stud shaft
- 45 Synchronizer hub
- 46 Drive flange
- 47 Spring
- 48 Sliding key ("dog")
- 49 Operating sleeve
- 50 Spring
- 51 Synchronizer ring
- 52 Lock ring
- 53 Spacer
- 54 Needle bearing
- 55 5th gear wheel
- 56 Spacer
- 57 Sleeve
- 58 Input shaft
- 59 Needle bearing
- 60 Lock ring
- 61 Synchronizer ring
- 62 Spring
- 63 Operating sleeve
- 64 Synchronizer hub
- 65 Synchronizer ring
- 66 3rd gear wheel
- 67 Sliding key
- 68 Main shaft
- 69 2nd gear wheel
- 70 Synchronizer ring
- 71 Operating sleeve
- 72 Spring
- 73 Synchronizer hub
- 74 Sliding key
- 75 Synchronizer ring
- 76 Lock ring
- 77 Washer
- 78 1st gear wheel
- 79 Damper cone
- 80 Spring
- 81 Drive flange
- 82 Thrust washer (if not equipped with damper)



1 R  
2 S  
3 T  
4 G  
5 S  
6 S  
7 L  
8 R  
9 S  
10 S  
11 V  
12 R  
13 G  
14 B  
15 R  
16 B  
17 T  
18 B  
19 B  
20 S  
t

## M 47 II Transmission components

(Fold-out 3)

21 V  
22 B  
23 G  
24 P  
25 S  
26 S  
27 G  
28 E  
29 S  
30 Ir  
31 V  
32 G  
33 L  
34 S  
t

35 B  
36 R  
37 S  
38 B  
39 S

# M 47 II Transmission components

- 1 Rear end cover
- 2 Seal
- 3 Top cover
- 4 Gasket
- 5 Spring
- 6 Selector plate
- 7 Lock ring
- 8 Reverse gear selector
- 9 Stud shaft
- 10 5th gear wheel
- 11 Washer
- 12 Rear housing
- 13 Gasket
- 14 Bearing outer race
- 15 Roller bearing
- 16 Bearing inner race
- 17 Thrust washer
- 18 Bearing outer race
- 19 Bearing inner race
- 20 Shim, thicknesses:


P/N	mm	in
3294334-2	0.10	0.004
3294335-9	0.15	0.006
3294336-7	0.25	0.010
3204069-3	0.55	0.022
3204070-1	0.75	0.030

- 21 Washer
- 22 Bolt
- 23 Gear selector
- 24 Pin
- 25 Selector shaft
- 26 Shift fork
- 27 Gear selector
- 28 Engaging lug
- 29 Spring
- 30 Interlocking ball
- 31 Washer
- 32 Guide pin
- 33 Lock ring
- 34 Shim, thicknesses:

P/N	mm	in
948008-8	0.60	0.024
948009-6	0.75	0.030
948010-4	0.90	0.036
948011-2	1.00	0.040

- 35 Ball bearing
- 36 Roller bearing
- 37 Seal
- 38 Ball bearing
- 39 Spacer

- 40 Gasket
- 41 Roller bearing
- 42 Bearing holder
- 43 Transmission housing
- 44 Gasket
- 45 Seal
- 46 Plug
- 47 Magnetic debris plug
- 48 Intermediate shaft
- 49 Reverse gear wheel
- 50 Stud shaft
- 51 Nut
- 52 Washer
- 53 Spring
- 54 Synchronizer ring
- 55 Sliding key ("dog")
- 56 Operating sleeve
- 57 Spring
- 58 Synchronizer ring
- 59 Washer
- 60 Gear wheel
- 61 Needle bearing
- 62 Shaft
- 63 Sleeve
- 64 Input shaft
- 65 Needle bearing
- 66 Lock ring
- 67 Synchronizer ring
- 68 Spring
- 69 Operating sleeve
- 70 Synchronizer hub
- 71 Spring
- 72 Synchronizer ring
- 73 3rd gear wheel
- 74 Main shaft
- 75 2nd gear wheel
- 76 Synchronizer ring
- 77 Spring
- 78 Operating sleeve
- 79 Synchronizer hub
- 80 Sliding key
- 81 Synchronizer ring
- 82 Lock ring
- 83 Washer
- 84 1st gear wheel
- 85 Brake cone
- 86 Spring
- 87 Drive flange
- 88 Damper
- 89 Thrust washer (if not equipped with damper)




**Type J, Overdrive  
components**

(Fold-out 4)

# Type J Overdrive components

- 1 Bridge
  - 2 Clutch piston
  - 3 O-ring
  - 4 Pin
  - 5 Guide pin
  - 6 Pump link
  - 7 Relief valve
  - 8 Spring
  - 9 Ball
  - 10 Front housing
  - 11 Spring
  - 12 Lock ring
  - 13 Clutch bearing
  - 14 Bearing holder
  - 15 Lock ring
  - 16 Oil filter
  - 17 Washer
  - 18 Plug
  - 19 Pump piston
  - 20 O-ring
  - 21 Pump cylinder
  - 22 Seat
  - 23 Ball
  - 24 Spring
  - 25 Plug
  - 26 O-ring
  - 27 O-ring
  - 28 O-ring
  - 29 Cylinder
  - 30 Piston
  - 31 Pressure adjusting shim, thicknesses:
- | P/N       | mm   | in     |
|-----------|------|--------|
| 1209450-4 | 0.05 | 0.0020 |
| 1209451-2 | 0.13 | 0.0052 |
| 1209452-0 | 0.25 | 0.0100 |
| 1209453-8 | 0.76 | 0.0300 |
- 46 Strainer
  - 47 Gasket
  - 48 Oil pan
  - 49 Spring washer
  - 50 Bolt
  - 51 Debris magnet
  - 52 Thrust washer
  - 53 Needle bearing
  - 54 Spacer washer
  - 55 Planetary gear wheel
  - 56 Oil slinger
  - 57 Lock pin
  - 58 Shaft
  - 59 Sun gear
  - 60 Planetary gear carrier
  - 61 Lock ring
  - 62 Race
  - 63 Roller cage
  - 64 One-way clutch hub
  - 65 One-way clutch
  - 66 Thrust washer
  - 67 Output shaft
  - 68 Ball bearing
  - 69 Speedometer drive gear
  - 70 Rear housing
  - 71 Spring washer
  - 72 Seal
  - 73 Ball bearing
  - 74 Seal
  - 75 Drive flange, round
  - 76 Drive flange, three-armed
  - 77 Washer
  - 78 Nut
  - 79 Seat

- 32 Relief valve assembly
- 33 O-ring
- 34 Plug
- 35 O-ring
- 36 Seal
- 37 Plug
- 38 O-ring
- 39 Seal
- 40 Solenoid valve
- 41 Gasket
- 42 Brake drum
- 43 Gasket
- 44 Lock ring
- 45 Clutch






**Type P Overdrive  
components**

(Fold-out 5)

# Type P Overdrive components

- 1 Bridge
  - 2 Clutch piston
  - 3 O-ring
  - 4 Teflon ring
  - 5 Pin
  - 6 Guide pin
  - 7 Pump link
  - 8 Front housing
  - 9 Spring
  - 10 Lock ring
  - 11 Lock ring
  - 12 Clutch bearing
  - 13 Bearing holder
  - 14 Oil filter
  - 15 Washer
  - 16 Plug
  - 17 Pump piston
  - 18 O-ring
  - 19 Cylinder
  - 20 Seat
  - 21 Ball
  - 22 Spring
  - 23 Plug
  - 24 O-ring
  - 25 O-ring
  - 26 O-ring
  - 27 Cylinder
  - 28 Pressure adjusting shim, thicknesses:
- | P/N       | mm   | in     |
|-----------|------|--------|
| 1209450-4 | 0.05 | 0.0020 |
| 1209451-2 | 0.13 | 0.0052 |
| 1209452-0 | 0.25 | 0.0100 |
| 1209453-8 | 0.76 | 0.0300 |
- 45 Strainer
  - 46 Gasket
  - 47 Oil pan
  - 48 Spring washer
  - 49 Bolt
  - 50 Debris magnet
  - 51 Thrust washer
  - 52 Needle bearing
  - 53 Spacer
  - 54 Planetary gear wheel
  - 55 Oil slinger
  - 56 Locking pin
  - 57 Sun gear
  - 58 Planetary gear carrier
  - 59 Shaft
  - 60 One-way clutch hub
  - 61 Thrust washer
  - 62 Race
  - 63 Roller cage
  - 64 Output shaft
  - 65 Ball bearing
  - 66 Spacer
  - 67 Rear housing
  - 68 Spring washer
  - 69 Seal
  - 70 Ball bearing
  - 71 Seal
  - 72 Drive flange, round
  - 73 Drive flange, three-armed
  - 74 Washer
  - 75 Nut
  - 76 Seat

- 30 Piston
- 31 Seal
- 32 Plug
- 33 Relief valve assembly
- 34 O-ring
- 35 Plug
- 36 O-ring
- 37 O-ring
- 38 Seal
- 39 Solenoid valve
- 40 Gasket
- 41 Brake drum
- 42 Gasket
- 43 Lock ring
- 44 Clutch



## Index

			Operation	Page				Operation	Page
<b>Check valve</b>									
Type J/Type P	removing	.....	E11-E12	57					
	installing	.....	G25-G27	69					
<b>Clutch assembly</b>									
Type J/Type P	dissassembling	...	E16-E17	58					
	assembling		G18.G23	69					
<b>Clutch housing</b>									
M46	removing	.....	A9-A10	11					
	installing	.....	B40-B43	22					
M47/M47II	removing	.....	C5-C6	29					
	installing	.....	D76-D79	53					
<b>Damper</b>									
M46	removing	.....	A22	13					
	installing	.....	B7-B9	16					
M47/M47II	checking	.....	D32	44					
	removing	.....	C40	35					
	installing	.....	D7-D9	40					
<b>Drive flange</b>									
M46	removing	.....	E26-E27	60					
	installing	.....	G10-G11	66					
M47/M47II	removing	.....	C8	30					
	installing	.....	D69	51					
<b>Drive flange seal</b>									
M46	removing	.....	E28	61					
	installing	.....	G5	65					
M47/M47II	removing	.....	C10	30					
	installing	.....	D64	51					
<b>Examining overdrive</b>									
Type J/Type P	.....		63						
<b>5th gear</b>									
M47	disassembling	...	C11-C21	30					
	assembling	.....	D33-D36	45					
M47II	.....		D42-D44	46					
	.....		D50-D55	48					
	disassembling	...	D17-D21	41					
	assembling	.....	C22-C31	32					
	.....		D37	45					
	.....		D45-D49	47					
	.....		D53-D55	48					
<b>Front housing</b>									
Type J/Type P	disassembling	...	E9-E15	56					
	assembling	.....	G24-G29	69					
<b>Gear lever support bracket (selector bracket)</b>									
M46	removing	.....	A3	10					
	installing	.....	B58-B59	26					
M47/M47II	removing	.....	C7	30					
	installing	.....	D67-D68	51					
					<b>Input shaft</b>				
					M46	removing	.....	A17	12
						disassembling	...	A27	14
						assembling	.....	B11-B12	17
						installing	.....	B31-B33	20
						adjusting shim		B36-B39	21
					M47/M47II	removing	.....	C35	34
						disassembling	...	C46	37
						assembling	.....	D11-D12	40
						installing	.....	D38-D40	46
						adjusting shim	...	D71-D75	52
					<b>Intermediate shaft (countershaft)</b>				
					M46	removing	.....	A15-A19	12
						disassembling	...	A26	14
						assembling	.....	B10	17
						installing	.....	B26-B34	19
						adjusting shim	...	B13-B21	17
						.....		B44-B45	23
					M47/M47II	.....			
						removing	.....	C32-C37	34
						disassembling	...	C45	36
						assembling	.....	D10	40
						installing	.....	D22-D27	43
						adjusting shim	...	D56-D62	50
					<b>Main shaft</b>				
					M46	removing	.....	A15-A18	12
						disassembling	...	A22-A25	13
						assembling	.....	B1-B9	15
						installing	.....	B27-B33	19
						adjusting shim	...	B46-B48	24
					M47/M47II	removing	.....	C33-C36	34
						disassembling	...	C40-C44	35
						assembling	.....	D1-D9	38
						installing	.....	D23-D26	42
						adjusting shim	...	D28-D31	43
					<b>Oil filter</b>				
					Type J/Type P	disassembling	...	E11-E12	57
						assembling	.....	G26-G27	70
					<b>Oil pressure test</b>				
					Type J/Type P	testing	.....		71
					<b>One-way clutch</b>				
					Type J	disassembling	...	E18-E21	58
						assembling	.....	G6-G9	65
					Type P	disassembling	...	E22-E25	60
						assembling	.....	G15-G17	67
					<b>Rear housing</b>				
					Type J	disassembling	...	E18-E21	58
						.....		E26-E32	60
						assembling	.....	G1-G12	64
					Type P	disassembling	...	E22-E32	60
						assembling	.....	G1-G5	64
						.....		G13-G17	66

## Index

### Operation Page

#### Relief valve

Type J/Type P disassembling . . .	E11–E14	57
assembling . . . . .	G26–G27	70

#### Reverse gear and shaft

M46 removing . . . . .	A20	13
installing . . . . .	B23–B25	19
M47/M47II removing . . . . .	C38	35
installing . . . . .	D13–D16	41

#### Shift forks

M46 removing . . . . .	A11–A14	11
installing . . . . .	B50–B52	25
M47/M47II removing . . . . .	C16–C18	31
installing . . . . .	D47–D49	47

#### Solenoid valve

Type J/Type P removing . . . . .	E1	55
installing . . . . .	G31	71

#### Transmission (top) cover

M46 removing . . . . .	A4–A5	10
installing . . . . .	B60–B65	27
M47/M47II removing . . . . .	C3–C4	29
installing . . . . .	D80–D84	54